

GIGABYTE™

R161-R12

High Efficiency Liquid Cooling System

User Manual

Rev. 1.1

Copyright

© 2019 GIGA-BYTE TECHNOLOGY CO., LTD. All rights reserved.

The trademarks mentioned in this manual are legally registered to their respective owners.

Disclaimer

Information in this manual is protected by copyright laws and is the property of GIGABYTE.

Changes to the specifications and features in this manual may be made by GIGABYTE without prior notice. No part of this manual may be reproduced, copied, translated, transmitted, or published in any form or by any means without GIGABYTE's prior written permission.

Documentation Classifications

In order to assist in the use of this product, GIGABYTE provides the following types of documentation:

- User Manual: detailed information & steps about the installation, configuration and use this product (e.g. motherboard, server barebones), covering hardware and BIOS.
- User Guide: detailed information about the installation & use of an add-on hardware or software component (e.g. BMC firmware, rail-kit) compatible with this product.
- Quick Installation Guide: a short guide with visual diagrams that you can reference easily for installation purposes of this product (e.g. motherboard, server barebones).

Please see the support section of the online product page to check the current availability of these documents

For More Information

For related product specifications, the latest firmware and software, and other information, please visit our website at: <http://www.gigabyte.com>.




For GIGABYTE distributors and resellers, additional sales & marketing materials are available from our reseller portal: <http://reseller.b2b.gigabyte.com>

For further technical assistance, please contact your GIGABYTE representative or visit <http://esupport.gigabyte.com/> to create a new support ticket.

For any general sales or marketing enquires, you may message GIGABYTE server directly by email: server.grp@gigabyte.com.

Conventions

The following conventions are used in this user's guide:

	NOTE! Gives bits and pieces of additional information related to the current topic.
	CAUTION! Gives precautionary measures to avoid possible hardware or software problems.
	WARNING! Alerts you to any damage that might result from doing or not doing specific actions.

Server Warnings and Cautions

Before installing a server, be sure that you understand the following warnings and cautions.



WARNING!

To reduce the risk of electric shock or damage to the equipment:

- Do not disable the power cord grounding plug. The grounding plug is an important safety feature.
- Plug the power cord into a grounded (earthed) electrical outlet that is easily accessible at all times.
- Unplug the power cord from the power supply to disconnect power to the equipment.
- Do not route the power cord where it can be walked on or pinched by items placed against it. Pay particular attention to the plug, electrical outlet, and the point where the cord extends from the server.



WARNING!

To reduce the risk of personal injury from hot surfaces, allow the drives and the internal system components to cool before touching them.



WARNING!

This server is equipped with high speed fans. Keep away from hazardous moving fan blades during servicing.



CAUTION!

- Do not operate the server for long periods with the access panel open or removed. Operating the server in this manner results in improper airflow and improper cooling that can lead to thermal damage.
- Danger of explosion if battery is incorrectly replaced.
- Replace only with the same or equivalent type recommended by the manufacturer.
- Dispose of used batteries according to the manufacturer's instructions.

Electrostatic Discharge (ESD)



CAUTION!

ESD CAN DAMAGE DRIVES, BOARDS, AND OTHER PARTS. WE RECOMMEND THAT YOU PERFORM ALL PROCEDURES AT AN ESD WORKSTATION. IF ONE IS NOT AVAILABLE, PROVIDE SOME ESD PROTECTION BY WEARING AN ANTI-STATIC WRIST STRAP ATTACHED TO CHASSIS GROUND -- ANY UNPAINTED METAL SURFACE -- ON YOUR SERVER WHEN HANDLING PARTS.

Always handle boards carefully. They can be extremely sensitive to ESD. Hold boards only by their edges without any component and pin touching. After removing a board from its protective wrapper or from the system, place the board component side up on a grounded, static free surface. Use a conductive foam pad if available but not the board wrapper. Do not slide board over any surface.

System power on/off: To remove power from system, you must remove the system from rack. Make sure the system is removed from the rack before opening the chassis, adding, or removing any non hot-plug components.

Hazardous conditions, devices and cables: Hazardous electrical conditions may be present on power, telephone, and communication cables. Turn off the system and disconnect the cables attached to the system before servicing it. Otherwise, personal injury or equipment damage can result.

Electrostatic discharge (ESD) and ESD protection: ESD can damage drives, boards, and other parts. We recommend that you perform all procedures in this chapter only at an ESD workstation. If one is not available, provide some ESD protection by wearing an antistatic wrist strap attached to chassis ground (any unpainted metal surface on the server) when handling parts.

ESD and handling boards: Always handle boards carefully. They can be extremely sensitive to electrostatic discharge (ESD). Hold boards only by their edges. After removing a board from its protective wrapper or from the system, place the board component side up on a grounded, static free surface. Use a conductive foam pad if available but not the board wrapper. Do not slide board over any surface.

Installing or removing jumpers: A jumper is a small plastic encased conductor that slips over two jumper pins. Some jumpers have a small tab on top that can be gripped with fingertips or with a pair of fine needle nosed pliers. If the jumpers do not have such a tab, take care when using needle nosed pliers to remove or install a jumper; grip the narrow sides of the jumper with the pliers, never the wide sides. Gripping the wide sides can damage the contacts inside the jumper, causing intermittent problems with the function controlled by that jumper. Take care to grip with, but not squeeze, the pliers or other tool used to remove a jumper, or the pins on the board may bend or break.

**CAUTION!**

Risk of explosion if battery is replaced incorrectly or with an incorrect type. Replace the battery only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

Table of Contents

Chapter 1	Hardware Installation	10
1-1	Installation Precautions	10
1-2	Product Specifications	11
1-3	System Block Diagram	14
Chapter 2	System Appearance	15
2-1	Front View	15
2-2	Rear View	15
2-3	Front Panel LED and Buttons	16
2-4	Rear System LAN LEDs	17
2-5	Hard Disk Drive LEDs	18
Chapter 3	System Hardware Installation	19
3-1	Removing Chassis Cover	20
3-2	Installing the Liquid Cooling Module	21
3-3	Installing the Memory	23
3-3-1	Four Channel Memory Configuration	23
3-3-2	Installing a Memory	24
3-3-3	DIMM Population Table	24
3-4	Installing the PCI Expansion Card	25
3-5	Installing the Hard Disk Drive	26
3-6	Replacing the FAN Assembly	27
3-7	Replacing the Power Supply	28
3-8	Cable Routing	29
Chapter 4	Motherboard Components	33
4-1	Motherboard Components	33
4-2	Jumper Setting	35
Chapter 5	BIOS Setup	36
5-1	The Main Menu	38
5-2	Advanced Menu	40
5-2-1	PCH-FW Configuration	41
5-2-2	Trusted Computing	42
5-2-3	SMART Settings	43
5-2-4	Serial Port Console Redirection	44
5-2-5	Intel TXT Information	48

5-2-6	Acoustic Management Configuration	49
5-2-7	SIO Configuration	50
5-2-8	PCI Subsystem Settings	51
5-2-9	Network Stack Configuration	52
5-2-10	Post Report Configuration	53
5-2-11	NVMe Configuration	54
5-2-12	USB Configuration	55
5-2-13	Chipset Configuration	56
5-2-14	Tls Auth Configuration	57
5-2-15	Intel(R) I350 Gigabit Network Connection	58
5-2-16	VLAN Configuration	60
5-2-17	Driver Health	62
5-3	Chipset Setup Menu	63
5-3-1	PCH-IO Configuration	64
5-3-2	Processor Configuration	66
5-3-3	Common RefCode Configuration	68
5-3-4	Memory Configuration	69
5-3-5	IIO Configuration	71
5-3-6	Advanced Power Management Configuraiton	73
5-3-7	Miscellaneous Configuration	75
5-3-8	Runtime Error Logging	76
5-4	OC Configuration Menu	88
5-4-1	Processor OverClocking	89
5-4-2	Memory OverClocking	92
5-4-3	Voltage Setting	93
5-4-4	Power & Performance	95
5-5	Server Management Menu	102
5-5-1	System Event Log	104
5-5-2	View FRU Information	105
5-5-3	BMC VLAN Configuration	106
5-5-4	BMC Network Configuration	107
5-5-5	IPv6 BMC Network Configuration	108
5-6	Security Menu	109
5-6-1	Secure Boot	110
5-7	Boot Menu	113
5-8	Save & Exit Menu	115
5-9	BIOS POST Codes	117
5-9-1	AMI Standard - PEI	117
5-9-2	AMI Standard - DXE	117
5-9-3	AMI Standard - ERROR	119

5-9-4	Intel UPI POST Codes.....	120
5-9-5	Intel UPI Error Codes	120
5-9-6	Intel MRC POST Codes	121
5-9-7	Intel MRC Error Codes	121
5-9-8	Intel PM POST Codes	122
5-9-9	Intel PM POST Codes	122
5-10	BIOS POST Beep code (AMI standard).....	123
5-10-1	PEI Beep Codes	123
5-10-2	DXE Beep Codes	123










Chapter 1 Hardware Installation






1-1 Installation Precautions

The motherboard/system contain numerous delicate electronic circuits and components which can become damaged as a result of electrostatic discharge (ESD). Prior to installation, carefully read the service guide and follow these procedures:

- Prior to installation, do not remove or break motherboard S/N (Serial Number) sticker or warranty sticker provided by your dealer. These stickers are required for warranty validation.
- Always remove the AC power by unplugging the power cord from the power outlet before installing or removing the motherboard or other hardware components.
- When connecting hardware components to the internal connectors on the motherboard, make sure they are connected tightly and securely.
- When handling the motherboard, avoid touching any metal leads or connectors.
- It is best to wear an electrostatic discharge (ESD) wrist strap when handling electronic components such as a motherboard, CPU or memory. If you do not have an ESD wrist strap, keep your hands dry and first touch a metal object to eliminate static electricity.
- Prior to installing the motherboard, please have it on top of an antistatic pad or within an electrostatic shielding container.
- Before unplugging the power supply cable from the motherboard, make sure the power supply has been turned off.
- Before turning on the power, make sure the power supply voltage has been set according to the local voltage standard.
- Before using the product, please verify that all cables and power connectors of your hardware components are connected.
- To prevent damage to the motherboard, do not allow screws to come in contact with the motherboard circuit or its components.
- Make sure there are no leftover screws or metal components placed on the motherboard or within the computer casing.
- Do not place the computer system on an uneven surface.
- Do not place the computer system in a high-temperature environment.
- Turning on the computer power during the installation process can lead to damage to system components as well as physical harm to the user.
- If you are uncertain about any installation steps or have a problem related to the use of the product, please consult a certified computer technician.


1-2 Product Specifications

 CPU	<ul style="list-style-type: none"> ◆ Intel® Core™ X series 44-lane/28-lane processors
Socket	<ul style="list-style-type: none"> ◆ Intel® Core™ X series 44-lane/28-lane processors
 Chipset	<ul style="list-style-type: none"> ◆ System on Chip
 Memory	<ul style="list-style-type: none"> ◆ 8 x DIMM slots ◆ DDR4 memory modules supported only ◆ Quad channel memory architecture ◆ Support for non-ECC Un-buffered DIMM ◆ DDR4 modules: 2667/2400/2133 MHz
 LAN	<ul style="list-style-type: none"> ◆ 2 x 1Gb/s LAN ports (Intel® I350-AM2) ◆ 1 x 10/100/1000 management LAN
 Expansion Slot	<ul style="list-style-type: none"> ◆ 1 x PCIe x16 slots (Gen3 x16), Low profile half-length* ◆ * The PCIe slot is unavailable for system level ◆ * The PCIe slot is shared with riser card 1 x PCIe x16 signal <p>Riser Card CRS1027:</p> <ul style="list-style-type: none"> ◆ 1 x PCIe x16 slots (Gen3 x16), Low profile half-length ◆ -1 x PCIe x16 slots (Gen3 x16), Low profile half-length <p>2 x M.2 slots:</p> <ul style="list-style-type: none"> ◆ - M-key ◆ - PCIe Gen3 x4 ◆ - Supports NGFF-2242/2260/2280 cards
 Video	<ul style="list-style-type: none"> ◆ Integrated in Aspeed® AST2500 ◆ 2D Video Graphic Adapter with PCIe bus interface ◆ 1920x1200@60Hz 32bpp, DDR4 SDRAM
 Storage	<ul style="list-style-type: none"> ◆ 2 x U.2, 2 x SATA/SAS or 4 x SATA/SAS hot-swappable HDD/SSD bays ◆ 2.5" HDD supported only
 SATA	<ul style="list-style-type: none"> ◆ Supported
 SAS	<ul style="list-style-type: none"> ◆ Supported via add-on SAS Card

	Internal Connectors	<ul style="list-style-type: none"> ◆ 3 x Power supply connectors ◆ 5 x SlimSAS connectors ◆ 2 x fan headers ◆ 1 x USB 3.0 header ◆ 1 x TPM header ◆ 1 x VROC connector ◆ 1 x Front panel header ◆ 1 x HDD back plane board header ◆ 1 x IPMB connector ◆ 1 x Clear CMOS jumper ◆ 1 x BIOS recovery jumper
	Front Panel LED/Buttons	<ul style="list-style-type: none"> ◆ 2 x USB 3.0 ◆ 1 x Power button with LED ◆ 1 x ID button with LED ◆ 1 x Reset button ◆ 1 x NMI button ◆ 1 x System status LED ◆ 1 x HDD activity LED ◆ 2 x LAN activity LEDs
	Rear Panel I/O	<ul style="list-style-type: none"> ◆ 2 x USB 3.0 ◆ 1 x VGA ◆ 1 x COM ◆ 2 x RJ45 ◆ 1 x MLAN
	Backplane I/O	<ul style="list-style-type: none"> ◆ Bandwidth: SATAIII 6Gb/s or SAS 12Gb/s or U.2 PCIe Gen3 x4 per port
	TPM	<ul style="list-style-type: none"> ◆ 1 x TPM header with LPC interface ◆ Optional TPM2.0 kit: CTM000


	System Management	<ul style="list-style-type: none"> ◆ Aspeed® AST2500 management controller ◆ Avocent® MergePoint IPMI 2.0 web interface: ◆ Network settings ◆ Network security settings ◆ Hardware information ◆ Users control ◆ Services settings ◆ IPMI settings ◆ Sessions control ◆ LDAP settings ◆ Power control ◆ Fan profiles ◆ Voltages, fans and temperatures monitoring ◆ System event log ◆ Events management (platform events, trap settings, email settings) ◆ Serial Over LAN ◆ vKVM & vMedia (HTML5)
	Power Supply	<ul style="list-style-type: none"> ◆ 2 x 1100W redundant PSUs ◆ 80 PLUS Platinum ◆ AC Input: ◆ - 100-240V~/ 12-6A, 50-60Hz ◆ DC Input: ◆ - 190-310Vdc/ 7A ◆ DC Output: ◆ - Max 850W/ 100-240Vac~ ◆ +12V/ 70A ◆ +5Vsb/ 3A ◆ - Max 1100W/ 200-240Vac ◆ +12V/ 90.5A ◆ +5Vsb/ 3A
	Environment Ambient Temperature Relative Humidity	<ul style="list-style-type: none"> ◆ Operating temperature: 10°C to 35°C ◆ Non-operating temperature: -40°C to 60°C ◆ Operating humidity: 8-80% (non-condensing) ◆ Non-operating humidity: 20%-95% (non-condensing)
	System Dimension	<ul style="list-style-type: none"> ◆ 1U ◆ 438mm (W) x 43.5mm (H) x 730mm (D)
<p>* We reserves the right to make any changes to the product specifications and product-related information without prior notice.</p>		

1-3 System Block Diagram



Chapter 2 System Appearance

2-1 Front View




No.	Description
1.	Front Panel LEDs and buttons
2.	Front USB 3.0 ports
Orange HDD Latches Support NVMe	




• Please Go to Chapter **2-3 Front Panel LED** and Buttons for detail description of function LEDs.

2-2 Rear View




No.	Description
1.	Power Supply Module Cord Socket
2.	Serial Port
3.	VGA Port
4.	USB 3.0 Port x 2
5.	10/100/1000 Server management LAN port
6.	GbE LAN Port #1
7.	GbE LAN Port #2
8.	PCIe Card bay x 2

2-3 Front Panel LED and Buttons




No.	Name	Color	Status	Description
1.	ID Button			Press the button to activate system identification
2.	Power button with LED	Green	On	System is powered on
		Green	Blink	System is in ACPI S1 state (sleep mode)
		N/A	Off	<ul style="list-style-type: none"> System is not powered on or in ACPI S5 state (power off) System is in ACPI S4 state (hibernate mode)
3.	Reset Button		Press the button to reset the system.	
4.	HDD Status LED	Green	On	HDD locate
			Blink	HDD access
		Amber	On	HDD fault
		Green/Amber	Blink	HDD rebuilding
		N/A	Off	No HDD access or no HDD fault.
5/6	LAN 1/2 Active/Link LEDs	Green	Solid On	Link between system and network or no access.
		Green	Blink	Data trasmission or receiving is occuring
		N/A	Off	No data transmission or receiving is occuring
7.	System Status LED	Green	Solid On	System is operating normally.
			Solid On	Critical condition, may indicate: System fan failure System temperature
		Amber	Blink	Non-critical condition, may indicate: Redundant power module failure Temperature and voltage issue Chassis intrusion
			Off	System is not ready, may indicate: POST error NMI error Processor or terminator missing
8.	NMI button			Press the button server generates a NMI to the processor if the multiple-bit ECC errors occur, which effectively halt the server.

2-4 Rear System LAN LEDs



No.	Name	Color	Status	Description
1.	1GbE Speed LED	Yellow	On	1 Gbps data rate
		Green	On	100 Mbps data rate
		N/A	Off	10 Mbps data rate
2.	1GbE Link/Activity LED	Green	On	Link between system and network or no access
		N/A	Blink	Data transmission or receiving is occurring
		N/A	Off	No data transmission or receiving is occurring

2-5 Hard Disk Drive LEDs



RAID SKU	LED1	Locate	HDD Fault	Rebuilding	HDD Access	HDD Present (No Access)
No RAID configuration (via HBA, ICH)	Disk LED (LED on Back Panel)	Green	ON(*1)	OFF	Green	OFF
		Amber	OFF	OFF	Amber	OFF
	Removed HDD Slot (LED on Back Panel)	Green	ON(*1)	OFF	Green	--
		Amber	OFF	OFF	Amber	--
RAID configuration (via HW RAID Card or SW RAID Card)	Disk LED	Green	ON	OFF	Alternately	OFF
		Amber	OFF	ON	(Low Speed: 2 Hz)	OFF
	Removed HDD Slot	Green	ON(*1)	OFF	(*3)	--
		Amber	OFF	ON	(*3)	--

LED 2	HDD Present	No HDD
Green	ON	OFF

NOTE:

*1: Depends on HBA/Utility Spec.

*2: Blink cycle depends on HDD's activity signal.

*3: If HDD is pulled out during rebuilding, the disk status of this HDD is regarded as faulty.

Chapter 3 System Hardware Installation



Pre-installation Instructions

Computer components and electronic circuit boards can be damaged by discharges of static electricity. Working on computers that are still connected to a power supply can be extremely dangerous. Follow the simple guidelines below to avoid damage to your computer or injury to yourself.

- Always disconnect the computer from the power outlet whenever you are working inside the computer case.
- If possible, wear a grounded wrist strap when you are working inside the computer case. Alternatively, discharge any static electricity by touching the bare metal system of the computer case, or the bare metal body of any other grounded appliance.
- Hold electronic circuit boards by the edges only. Do not touch the components on the board unless it is necessary to do so. Do not flex or stress the circuit board.
- Leave all components inside the static-proof packaging until you are ready to use the component for the installation.

3-1 Removing Chassis Cover




Before you remove or install the system cover

- Make sure the system is not turned on or connected to AC power.

Follow these instructions to remove the system cover:

1. Loosen and the two thumbscrew at the rear of the system.
2. Remove the single screw at the front of the system.
3. Push down the indentation located at the side of the back chassis
4. Using the grip areas on the top cover and slide the cover horizontally in the direction of the arrow.



3-2 Installing the Liquid Cooling Module







Before you remove or install the liquid cooling module:

- Make sure the system is not turned on or connected to AC power.

Follow these instructions to install the liquid cooling module:

1. Remove the screws securing brackets .
2. Remove the brackets from the system.
3. Engage the brackets and radiators.
4. Secure the brackets and radiators with 6 screws.
5. Lock the four spring screws.
NOTE! Remove the pump grease protection cover before installing the pump.
6. Install the fan duct and secure with 2 screws.
7. Connect pump cable to motherboard.





3-3 Installing the Memory




Read the following guidelines before you begin to install the memory:

- Make sure that the motherboard supports the memory. It is recommended that memory of the same capacity, brand, speed, and chips be used.
- Always turn off the computer and unplug the power cord from the power outlet before installing the memory to prevent hardware damage.
- Memory modules have a foolproof design. A memory module can be installed in only one direction. If you are unable to insert the memory, switch the direction.

3-3-1 Four Channel Memory Configuration

This motherboard provides 8 DDR4 memory sockets and supports Four Channel Technology. After the memory is installed, the BIOS will automatically detect the specifications and capacity of the memory. Enabling Four Channel memory mode will be four times of the original memory bandwidth.



3-3-2 Installing a Memory




Before installing a memory module, make sure to turn off the computer and unplug the power cord from the power outlet to prevent damage to the memory module.

Be sure to install DDR4 DIMMs on this motherboard.

Follow these instructions to install the Memory:

1. Insert the DIMM memory module vertically into the DIMM slot, and push it down.
2. Close the plastic clip at both edges of the DIMM slots to lock the DIMM module.
3. Reverse the installation steps when you want to remove the DIMM module.



3-3-3 DIMM Population Table

Type	Ranks Per DIMM and Data Width	DIMM Capacity (GB)		Speed (MT/s); Voltage (V) Slot Per Channel (SPC) DIMM Per Channel (DPC)		
				1 Slot per Channel	2 Slot per Channel	
		DIMM Density		1DPC	1DPC	2DPC
		4Gb	8Gb	1.2V	1.2V	1.2V
UDIMM	SRx4	4GB	8GB	2666	2666	2666
UDIMM	SRx8	8GB	16GB			
UDIMM	DRx8	8GB	16GB			
UDIMM	DRx8	16GB	32GB			

3-4 Installing the PCI Expansion Card



- Voltages can be present within the server whenever an AC power source is connected. This voltage is present even when the main power switch is in the off position. Ensure that the system is powered-down and all power sources have been disconnected from the server prior to installing a PCI card.


Failure to observe these warnings could result in personal injury or damage to equipment.



- The PCI riser assembly does not include a riser card or any cabling as standard. To install a PCI card, a riser card must be installed.

Follow these instructions to PCI Expansion card:

1. Remove the securing special screw on the riser bracket.
2. Loosen the thumbscrew on the riser bracket
3. Lift up the riser bracket out of system.
4. Remove the slot covers from the riser bracket.
5. Orient the PCI-E card with the riser guide slot and push in the direction of the arrow until the PCI-E card sits in the PCI card connector.
6. Secure the PCI-E card with the screw.
7. Reverse the steps 3 - 1 to install the riser bracket.



3-5 Installing the Hard Disk Drive





Read the following guidelines before you begin to install the Hard disk drive:

- Take note of the drive tray orientation before sliding it out.
- The tray will not fit back into the bay if inserted incorrectly.
- Make sure that the HDD is connected to the HDD connector on the backplane.

Follow these instructions to install a hard disk drive:


1. Press the release button.
2. Extend the locking lever and pull the locking lever to remove the HDD tray.
3. Place the hard disk drive into the HDD tray.
4. Secure the hard disk drive to the HDD tray with four screws.



3-6 Replacing the FAN Assembly

Follow these instructions to replace the fan assembly:


1. Lift up the fan assembly from the chassis.
2. Reverse the previous steps to install the replacement fan assembly.



3-7 Replacing the Power Supply


Follow these instructions to replace the power supply:

1. Press the retaining clip on the right side of the power supply along the direction of the arrow.
2. Pull up the power supply handle at the same time and pull out the power supply.
3. Insert the replacement power supply firmly into the chassis. Connect the AC power cord to the replacement power supply.




3-8 Cable Routing


System Power Cable




Front IO Board Power Cable




Front Panel USB 3.0 Cable




Front IO Board Power Cable



HDD Back Plane Board Power Cable





HDD Back Plane Board Signal Cable




On-Board SATA to HDD Back Plane Board NVMe Cable

Cable



System Fan Cable




CAUTION!


To connect system fan connector, follow the instruction:

- Black/Red cable connect to odd numbered connector.
- White/Amber cable connect to even numbered connector.

SMBus Cable




PMBus Cable



Chapter 4 Motherboard Components


4-1 Motherboard Components



Item	Description
1	2 x 4 Pin CPU Power Connector
2	Auxiliary Power Connector for Overclocking
3	2 x 12 Pin System Power Connector
4	Front Panel Header
5	VROC Upgrade Module
6	CPU Fan Connector (for Liquid Cooling Pump)
7	SlimLine 4i Connector (PCIe Signal)
8	SlimLine 4i Connector (PCIe Signal)
9	SlimLine 4i Connector (PCIe Signal)
10	M.2 slot (PCIe Gen3 x4, Support NGFF-2280, M-Key)
11	SlimLine 4i Connector (SATA Signal)
12	SlimLine 4i Connector (SATA Signal)
13	Front Panel Board Power Connector

14	USB 3.0 Connector
15	TPM Connector
16	System Battery Cable Connector
17	PMBus Connector
18	M.2 slot (PCIe Gen3 x4, Support NGFF-2280, M-Key)
19	IPMB Connector
20	Proprietary Riser Slot
21	2 x 15 Pin HDD Back Plane Board Connector
22	PCIe x16 Slot

4-2 Jumper Setting



Chapter 5 BIOS Setup

BIOS (Basic Input and Output System) records hardware parameters of the system in the EFI on the motherboard. Its major functions include conducting the Power-On Self-Test (POST) during system startup, saving system parameters and loading operating system, etc. BIOS includes a BIOS Setup program that allows the user to modify basic system configuration settings or to activate certain system features. When the power is turned off, the battery on the motherboard supplies the necessary power to the CMOS to keep the configuration values in the CMOS.

To access the BIOS Setup program, press the key during the POST when the power is turned on.



- BIOS flashing is potentially risky, if you do not encounter problems of using the current BIOS version, it is recommended that you don't flash the BIOS. To flash the BIOS, do it with caution. Inadequate BIOS flashing may result in system malfunction.
- It is recommended that you not alter the default settings (unless you need to) to prevent system instability or other unexpected results. Inadequately altering the settings may result in system's failure to boot. If this occurs, try to clear the CMOS values and reset the board to default values. (Refer to the **Exit** section in this chapter or introductions of the battery/clearing CMOS jumper in Chapter 1 for how to clear the CMOS values.)

BIOS Setup Program Function Keys

<<-><->>	Move the selection bar to select the screen
<↑><↓>	Move the selection bar to select an item
<+>	Increase the numeric value or make changes
<->	Decrease the numeric value or make changes
<Enter>	Execute command or enter the submenu
<Esc>	Main Menu: Exit the BIOS Setup program Submenus: Exit current submenu
<F1>	Show descriptions of general help
<F3>	Restore the previous BIOS settings for the current submenus
<F9>	Load the Optimized BIOS default settings for the current submenus
<F10>	Save all the changes and exit the BIOS Setup program

■ **Main**

This setup page includes all the items in standard compatible BIOS.

■ **Advanced**

This setup page includes all the items of AMI BIOS special enhanced features.

(ex: Auto detect fan and temperature status, automatically configure hard disk parameters.)

■ **Chipset**

This setup page includes all the submenu options for configuring the functions of the Platform Controller Hub.

■ **OC Config**

This setup page provides items for overclocking configuration.

■ **Server Mgmt**

Server additional features enabled/disabled setup menus.

■ **Security**

Change, set, or disable supervisor and user password. Configuration supervisor password allows you to restrict access to the system and BIOS Setup.

A supervisor password allows you to make changes in BIOS Setup.

A user password only allows you to view the BIOS settings but not to make changes.

■ **Boot**

This setup page provides items for configuration of boot sequence.

■ **Save & Exit**

Save all the changes made in the BIOS Setup program to the CMOS and exit BIOS Setup. (Pressing <F10> can also carry out this task.)

Abandon all changes and the previous settings remain in effect. Pressing <Y> to the confirmation message will exit BIOS Setup. (Pressing <Esc> can also carry out this task.)

5-1 The Main Menu

Once you enter the BIOS Setup program, the Main Menu (as shown below) appears on the screen. Use arrow keys to move among the items and press <Enter> to accept or enter other sub-menu.

Main Menu Help

The on-screen description of a highlighted setup option is displayed on the bottom line of the Main Menu.

Submenu Help

While in a submenu, press <F1> to display a help screen (General Help) of function keys available for the menu. Press <Esc> to exit the help screen. Help for each item is in the Item Help block on the right side of the submenu.



- When the system is not stable as usual, select the **Restore Defaults** item to set your system to its defaults.
- The BIOS Setup menus described in this chapter are for reference only and may differ by BIOS version.

<ul style="list-style-type: none"> <li style="background-color: #f4a460; padding: 5px;">Main <li style="padding: 5px;">Advanced <li style="padding: 5px;">Chipset <li style="padding: 5px;">OC Config <li style="padding: 5px;">Server Mgmt <li style="padding: 5px;">Security <li style="padding: 5px;">Boot <li style="padding: 5px;">Save & Exit 	<p>BIOS Information</p> <p>Access Level Administrator</p> <p>Project Name MR11-LC0-00</p> <p>Project Version F03</p> <p>Build Date and Time 10/18/2018 14:52:24</p> <p>BMC Information</p> <p>BMC Firmware Version 01.72</p> <p>Processor Information</p> <p>CPU Brand String Intel(R) Core(TM) i7-9800X CPU @ 3.80GHz</p> <p>Max CPU Speed 3800 MHz</p> <p>CPU Signature 50654</p> <p>Processor Core 8</p>
---	--


<ul style="list-style-type: none"> <li style="background-color: #f4a460; padding: 5px;">Main <li style="padding: 5px;">Advanced <li style="padding: 5px;">Chipset <li style="padding: 5px;">OC Config <li style="padding: 5px;">Server Mgmt <li style="padding: 5px;">Security <li style="padding: 5px;">Boot <li style="padding: 5px;">Save & Exit 	<p>Microcode Patch 0200004D</p> <p>Memory Information</p> <p>Total Memory 32768 MB</p> <p>Memory Frequency 2400 MHz</p> <p>Onboard LAN Information</p> <p>LAN1 MAC Address E0-D5-5E-E7-6D-DB</p> <p>LAN2 MAC Address E0-D5-5E-E7-6D-DC</p> <p>System Date 02/14/2019</p> <p><small>Set the Date. Use Tab to switch between Date elements. Default Ranges: Year: 2017-2099 Months: 1-12 Days: dependent on month</small></p> <p>System Time 11:11:27</p> <p><small>Set the Time. Use Tab to switch between Time elements.</small></p>
---	--

Parameter	Description
BIOS Information	
Access Level	Display the privileges level information.
Project Name	Displays the project name information.
Project Version	Displays version number of the BIOS setup utility.
Build Date and Time	Displays the date and time when the BIOS setup utility was created.
BMC Information ^(Note)	
BMC Firmware Version ^(Note)	Displays BMC firmware version information.
Processor Information	
CPU Brand String / Max CPU Speed / CPU Signature / Processor Core / Microcode Patch	Displays the technical specifications for the installed processor(s).
Memory Information	
Total Memory ^(Note)	Displays the total memory size of the installed memory.
Memory Frequency ^(Note)	Displays the frequency information of the installed memory.
Onboard LAN Information	
LAN1 MAC Address ^(Note)	Displays LAN MAC address information.
LAN2 MAC Address ^(Note)	Displays LAN MAC address information.
System Date	Sets the date following the weekday-month-day-year format.
System Time	Sets the system time following the hour-minute-second format.

(Note) Functions available on selected models.

5-2 Advanced Menu

The Advanced menu display submenu options for configuring the function of various hardware components. Select a submenu item, then press <Enter> to access the related submenu screen.




5-2-1 PCH-FW Configuration

The screenshot displays the BIOS PCH-FW Configuration interface. The left sidebar shows navigation options: Main, **Advanced**, Chipset, OC Config, Server Mgmt, Security, Boot, and Save & Exit. The main area shows the following configuration details:

- ME Firmware Version:** 11.11.55.1509 (ME Firmware Version)
- ME Firmware Mode:** Normal Mode (ME Firmware Mode)
- ME Firmware SKU:** Consumer SKU (ME Firmware SKU)
- ME File System Integrity Value:** 2 (ME File System Integrity Value)
- ME Firmware Status 1:** 0x90000255 (ME Firmware Status 1)
- ME Firmware Status 2:** 0x6B000316 (ME Firmware Status 2)
- Current State:** Operational (ME firmware Current State, bits [3:0] in MEFS1)
- Error Code:** No Error (ME firmware Error Code, bits [15:12] in MEFS1)
- Recovery Cause:** N/A (Server ME firmware recovery cause, bits [10:8] in MEFS2)
- NFC Support:** Disabled (Enables support for NFC)
- ME State:** Enabled (dropdown menu)


Parameter	Description
ME Firmware Version	Displays the ME firmware version information.
ME Firmware Mode	Displays the ME firmware mode.
ME Firmware SKU	Displays the ME firmware SKU information.
ME File System Integrity Value	Displays the ME file system integrity value information.
ME Firmware Status 1/2	Displays the ME firmware status 1/2 information.
Current State	Displays the current state of ME firmware.
Error Code	Displays the ME firmware error code information.
Recovery Cause	Displays the cause of ME firmware recovery.
NFC Support	Displays the NFC status.
ME State	Enable/Disable ME state. Options available: Enabled/Disabled. Default setting is Enabled .

5-2-2 Trusted Computing




Parameter	Description
Configuration	
Security Device Support	Enable/Disable the TPM support feature. Options available: Enable/Disable. Default setting is Enable .

5-2-3 SMART Settings



Parameter	Description
SMART Settings	
SMART Self Test	Enable/Disable SMART Self Test on all HDDs during POST. Options available: Enabled/Disabled. Default setting is Enabled .

5-2-4 Serial Port Console Redirection



Parameter	Description
COM1 Console Redirection ^(Note)	<p>Console redirection enables the users to manage the system from a remote location.</p> <p>Options available: Enabled/Disabled. Default setting is Disabled.</p>
COM1 Console Redirection Settings	<p>Press [Enter] to configure advanced items.</p> <p>Please note that this item is configurable when COM1 Console Redirection is set to Enabled.</p> <ul style="list-style-type: none"> ◆ Terminal Type <ul style="list-style-type: none"> – Selects a terminal type to be used for console redirection. – Options available: VT100, VT100+, ANSI, VT-UTF8. Default setting is VT100+. ◆ Bits per second <ul style="list-style-type: none"> – Selects the transfer rate for console redirection. – Options available: 9600, 19200, 38400, 57600, 115200. Default setting is 115200. ◆ Data Bits <ul style="list-style-type: none"> – Selects the number of data bits used for console redirection. – Options available: 7/8. Default setting is 8.

(Note) Advanced items prompt when this item is defined.

Parameter	Description
COM1 Console Redirection Settings (continued)	<ul style="list-style-type: none"> ◆ Parity <ul style="list-style-type: none"> – A parity bit can be sent with the data bits to detect some transmission errors. – Even: parity bit is 0 if the num of 1's in the data bits is even. – Odd: parity bit is 0 if num of 1's in the data bits is odd. – Mark: parity bit is always 1. Space: Parity bit is always 0. – Mark and Space Parity do not allow for error detection. – Options available: None, Even, Odd, Mark, Space. Default setting is None. ◆ Stop Bits <ul style="list-style-type: none"> – Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning). The standard setting is 1 stop bit. Communication with slow devices may require more than 1 stop bit. – Options available: 1/2. Default setting is 1. ◆ Flow Control <ul style="list-style-type: none"> – Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a 'stop' signal can be sent to stop the data flow. Once the buffers are empty, a 'start' signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals. – Options available: None, Hardware RTS/CTS. Default setting is None. ◆ VT-UTF8 Combo Key Support <ul style="list-style-type: none"> – Enable/Disable the VT-UTF8 Combo Key Support. – Options available: Enabled/Disabled. Default setting is Enabled. ◆ Recorder Mode^(Note) <ul style="list-style-type: none"> – When this mode enabled, only texts will be send. This is to capture Terminal data. – Options available: Enabled/Disabled. Default setting is Disabled. ◆ Resolution 100x31^(Note) <ul style="list-style-type: none"> – Enable/Disable extended terminal resolution. – Options available: Enabled/Disabled. Default setting is Enabled. ◆ Putty KeyPad^(Note) <ul style="list-style-type: none"> – Selects FunctionKey and LeyPad on Putty. – Options available: VT100, LINUX, XTERMR6, SC0, ESCN, VT400. Default setting is VT100.


(Note) Advanced items prompt when this item is defined.

Parameter	Description
Legacy Console Redirection	
Legacy Console Redirection Settings	<p>Press [Enter] to configure advanced items.</p> <ul style="list-style-type: none"> ◆ Redirection COM Port <ul style="list-style-type: none"> – Selects a COM port for Legacy serial redirection. – Default setting is COM1. ◆ Resolution <ul style="list-style-type: none"> – Selects the number of rows and columns used in Console Redirection for legacy OS support. – Options available: 80x24, 80x25. Default setting is 80x24. ◆ Redirect After POST <ul style="list-style-type: none"> – When Bootloader is selected, then Legacy Console Redirection is disabled before booting to legacy OS. When Always Enable is selected, then Legacy Console Redirection is enabled for legacy OS. – Options available: Always Enable, BootLoader. Default setting is Always Enable.
Serial Port for Out-of-Band Management / Windows Emergency Management Services (EMS) Console Redirection ^(Note)	<p>EMS console redirection allows the user to configure Console Redirection Settings to support Out-of-Band Serial Port management.</p> <p>Options available: Enabled/Disabled. Default setting is Disabled.</p>
Serial Port for Out-of-Band EMS Console Redirection Settings	<p>Press [Enter] to configure advanced items.</p> <p>Please note that this item is configurable when Serial Port for Out-of-Band Management EMS Console Redirection is set to Enabled.</p> <ul style="list-style-type: none"> ◆ Out-of-Band Mgmt Port <ul style="list-style-type: none"> – Microsoft Windows Emergency Management Service (EMS) allows for remote management of a Windows Server OS through a serial port. – Default setting is COM1. ◆ Terminal Type <ul style="list-style-type: none"> – Selects a terminal type to be used for console redirection. – Options available: VT100, VT100+, ANSI, VT-UTF8. Default setting is VT100+. ◆ Bits per second <ul style="list-style-type: none"> – Selects the transfer rate for console redirection. – Options available: 9600, 19200, 38400, 57600, 115200. Default setting is 115200.

(Note) Advanced items prompt when this item is defined.


Parameter	Description
Serial Port for Out-of-Band EMS Console Redirection Settings(continued)	<ul style="list-style-type: none">◆ Flow Control<ul style="list-style-type: none">– Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a 'stop' signal can be sent to stop the data flow. Once the buffers are empty, a 'start' signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.– Options available: None, Hardware RTS/CTS, Software Xon/Xoff. Default setting is None.

5-2-5 Intel TXT Information




Parameter	Description
Intel TXT Information	
Chipset	Displays the chipset is production or debug fused.
BiosAcm	Displays the Bios Acm is production or debug fused.
Chipset Txt	Displays the chipset status of TXT support.
Cpu Txt	Displays the CPU status of TXT support.
Error Code	Displays the Intel TXT shut down error code.
Class Code	Displays the class code information.
Major Code	Displays the major code information.
Minor Code	Displays the minor code information.

5-2-6 Acoustic Management Configuration




Parameter	Description
Acoustic Management Configuration	Enable/Disable the automatic acoustic management function. Options available: Enabled/Disabled. Default setting is Disabled .

5-2-7 SIO Configuration




Parameter	Description
AMI SIO Driver Version	Displays the AMI SIO driver version information.
Super IO Chip Logical Device(s) Configuration	
Press [Enter] to configure advanced items.	
◆ Use This Device	<ul style="list-style-type: none"> – When set to Enabled allows you to configure the serial port settings. When set to Disabled, displays no configuration for the serial port. – Options available: Enabled/Disabled. Default setting is Enabled.
◆ Current:	<ul style="list-style-type: none"> – Displays the serial port base I/O address and IRQ.
◆ Possible:	<ul style="list-style-type: none"> – Configures the serial port base I/O address and IRQ.
Use Automatic Settings	
IO=3F8h; IRQ=4; DMA;	
IO=3F8h; IRQ=3, 4, 5, 7, 9, 10, 11, 12; DMA;	
IO=2F8h; IRQ=3, 4, 5, 7, 9, 10, 11, 12; DMA;	
IO=3E8h; IRQ=3, 4, 5, 7, 9, 10, 11, 12; DMA;	
IO=2E8h; IRQ=3, 4, 5, 7, 9, 10, 11, 12; DMA;	
Default setting is Use Automatic Settings .	
[Active] Serial Port	

5-2-8 PCI Subsystem Settings



Parameter	Description
PCI Bus Driver Version	Displays the PCI Bus Driver version information.
PCI Devices Common Settings	
PERR# Generation	Enable/Disable PCI device to generate PERR#. Options available: Enabled/Disabled. Default setting is Disabled .
SERR# Generation	Enable/Disable PCI device to generate SERR#. Options available: Enabled/Disabled. Default setting is Disabled .
Above 4G Decoding	Enable/Disable 64bit capable Devices to be decoded in Above 4G Address Space (only if the system supports 64 bit PCI Decoding). Options available: Enabled/Disabled. Default setting is Enabled .
BME DMA Mitigation	Re-enable bus master attribute disabled during PCI enumeration for PCI bridges after SMM is locked. Options available: Enabled/Disabled. Default setting is Enabled .


5-2-9 Network Stack Configuration



Parameter	Description
Network Stack	Enable/Disable the UEFI network stack. Options available: Enabled/Disabled. Default setting is Enabled .
Ipv4 PXE Support ^(Note)	Enable/Disable the Ipv4 PXE feature. Options available: Enabled/Disabled. Default setting is Enabled .
Ipv4 HTTP Support ^(Note)	Enable/Disable the Ipv4 HTTP feature. Options available: Enabled/Disabled. Default setting is Disabled .
Ipv6 PXE Support ^(Note)	Enable/Disable the Ipv6 PXE feature. Options available: Enabled/Disabled. Default setting is Enabled .
Ipv6 HTTP Support ^(Note)	Enable/Disable the Ipv6 HTTP feature. Options available: Enabled/Disabled. Default setting is Disabled .
PXE boot wait time ^(Note)	Wait time in seconds to press ESC key to abort the PXE boot. Press the <+> / <-> keys to increase or decrease the desired values.
Media detect count ^(Note)	Number of times the presence of media will be checked. Press the <+> / <-> keys to increase or decrease the desired values.


(Note) This item appears when **Network Stack** is set to **Enabled**.

5-2-10 Post Report Configuration




Parameter	Description
Post Report Configuration	
Error Message Report	
Post Error Message	Enable/Disable the POST Error Message support. Options available: Enabled/Disabled. Default setting is Enabled .

5-2-11 NVMe Configuration



Parameter	Description
NVMe Configuration	Displays the NVMe devices connected to the system


5-2-12 USB Configuration



Parameter	Description
USB Configuration	
USB Devices:	Displays the USB devices connected to the system.
XHCI Hand-off	Enable/Disable the XHCI (USB 3.0) Hand-off support. Options available: Enabled/Disabled. Default setting is Enabled .
USB Mass Storage Driver Support ^(Note)	Enable/Disable the USB Mass Storage Driver Support. Options available: Enabled/Disabled. Default setting is Enabled .
Port 60/64 Emulation	Enables the I/O port 60h/64h emulation support. This should be enabled for the complete USB Keyboard Legacy support for non-USB aware OS. Options available: Enabled/Disabled. Default setting is Enabled .

(Note) This item is present only if you attach USB devices.


5-2-13 Chipset Configuration



Parameter	Description
Restore on AC Power Loss ^(Note)	Defines the power state to resume to after a system shutdown that is due to an interruption in AC power. When set to Last State, the system will return to the active power state prior to shutdown. When set to Power Off, the system remains off after power shutdown. Options available: Last State, Power Off, Power On, Unspecified. The default setting depends on the BMC setting.
Skip Above 4G Decoding for VGA	Enable/Disable 64bit capable devices to be decoded in Skip Above 4G Address VGA Space. Options available: Enabled/Disabled. Default setting is Disabled .
P2P Bridge IO Size	Sets P2P Bridge IO aligned to the size. Options available: 0x100, 0x150, 0x1000. Default setting is 0x1000 .
Chassis Opened Warning	Enable/Disable the chassis intrusion alert function. Options available: Enabled, Disabled, Clear. Default setting is Disabled .


(Note) When the power policy is controlled by BMC, please wait for 15-20 seconds for BMC to save the last power state.

5-2-14 Tls Auth Configuration



Parameter	Description
Server CA Configuration	<p>Press [Enter] for configuration of advanced items.</p> <ul style="list-style-type: none"> ◆ Enroll Cert <ul style="list-style-type: none"> – Press [Enter] to enroll a certificate <ul style="list-style-type: none"> • Enroll Cert Using File • Cert GUID <ul style="list-style-type: none"> Input digit character in 1111111-2222-3333-4444-1234567890ab format. – Commit Changes and Exit – Discard Changes and Exit ◆ Delete Cert
Client Cert Configuration	<p>Press [Enter] for configuration of advanced items.</p>



5-2-15 Intel(R) I350 Gigabit Network Connection



Parameter	Description
NIC Configuration	<p>Press [Enter] to configure advanced items.</p> <ul style="list-style-type: none"> ◆ Link Speed <ul style="list-style-type: none"> – Allows for automatic link speed adjustment. – Options available: Auto Negotiated, 10 Mbps Half, 10 Mbps Full, 100 Mbps Half, 100 Mbps Full. Default setting is Auto Negotiated. ◆ Wake On LAN <ul style="list-style-type: none"> – Enables power on of the system via LAN. Note that configuring Wake on LAN in the operating system does not change the value of this setting, but does override the behavior of Wake on LAN in OS controlled power states. – Options available: Enabled/Disabled. Default setting is Enabled.
Blink LEDs	Identifies the physical network port by blinking the associated LED. Press the numeric keys to adjust desired values.
UEFI Driver	Displays the technical specifications for the Network Interface Controller.
Adapter PBA	Displays the technical specifications for the Network Interface Controller.
Device Name	Displays the technical specifications for the Network Interface Controller.


Parameter	Description
Chip Type	Displays the technical specifications for the Network Interface Controller.
PCI Device ID	Displays the technical specifications for the Network Interface Controller.
PCI Address	Displays the technical specifications for the Network Interface Controller.
Link Status	Displays the technical specifications for the Network Interface Controller.
MAC Address	Displays the technical specifications for the Network Interface Controller.
Virtual MAC Address	Displays the technical specifications for the Network Interface Controller.

5-2-16 VLAN Configuration



Parameter	Description
Enter Configuration Menu	<p data-bbox="341 153 671 174">Press [Enter] to configure advanced items.</p> <ul style="list-style-type: none"> <li data-bbox="341 185 519 205">◆ Create new VLAN <li data-bbox="341 216 937 323">◆ VLAN ID <ul style="list-style-type: none"> <li data-bbox="378 241 804 261">– Sets VLAN ID for a new VLAN or an existing VLAN. <li data-bbox="378 272 937 293">– Press the <+> / <-> keys to increase or decrease the desired values. <li data-bbox="378 304 663 324">– The valid range is from 0 to 4094. <li data-bbox="341 333 937 440">◆ Priority <ul style="list-style-type: none"> <li data-bbox="378 359 852 379">– Sets 802.1Q Priority for a new VLAN or an existing VLAN. <li data-bbox="378 390 937 410">– Press the <+> / <-> keys to increase or decrease the desired values. <li data-bbox="378 421 636 442">– The valid range is from 0 to 7. <li data-bbox="341 451 905 498">◆ Add VLAN <ul style="list-style-type: none"> <li data-bbox="378 476 905 497">– Press [Enter] to create a new VLAN or update an existing VLAN. <li data-bbox="341 509 551 529">◆ Configured VLAN List <li data-bbox="341 540 732 588">◆ Remove VLAN <ul style="list-style-type: none"> <li data-bbox="378 566 732 586">– Press [Enter] to remove an existing VLAN.


5-2-17 Driver Health




Parameter	Description
Driver Health	Displays driver health status of the devices/controllers if installed

5-3 Chipset Setup Menu

Chipset Setup menu displays submenu options for configuring the function of Platform Controller Hub(PCH). Select a submenu item, then press <Enter> to access the related submenu screen.



5-3-1 PCH-IO Configuration



Parameter	Description
PCH-IO Configuration	<p>Press [Enter] to configure advanced items.</p> <ul style="list-style-type: none"> ◆ SATA Controller <ul style="list-style-type: none"> – Enable/Disable SATA device. – Options available: Enabled/Disabled. Default setting is Enabled. ◆ SATA Mode Selection <ul style="list-style-type: none"> – Configures on chip SATA type. – AHCI Mode: the SATA controller enables its AHCI functionality. Then the RAID function is disabled and cannot be access the RAID setup utility at boot time. – Intel RST Premium: the SATA controller enables both its RAID and AHCI functions. You will be allowed to access the RAID setup utility at boot time. – Options available: AHCI/Intel RST Premium. Default setting is AHCI. ◆ SATA Port 0/1/2/3/4/5/6/7 <ul style="list-style-type: none"> – The category identifies SATA hard drives that are installed in the computer. System will automatically detect HDD type. ◆ Port 0/1/2/3/4/5/6/7 <ul style="list-style-type: none"> – Enable/Disable Port 0/1/2/3/4/5/6/7 device. – Options available: Enabled/Disabled. Default setting is Enabled. ◆ Hot Plug (for Port 0/1/2/3/4/5/6/7) <ul style="list-style-type: none"> – Enable/Disable SATA ports Hot Plug support. – Options available: Enabled/Disabled. Default setting is Enabled
SATA And RST Configuration	

Parameter	Description
SATA And RST Configuration (continued)	<ul style="list-style-type: none">◆ Spin Up Device<ul style="list-style-type: none">– Enable/Disable the SATA ports staggered spin up function.– Options available: Enabled/Disabled. Default setting is Disabled

5-3-2 Processor Configuration

Processor Configuration

Per-Socket Configuration

Change Per-Socket Settings

Processor ID	00050654*
Processor Frequency	3.800GHz
Processor Max Ratio	26H
Processor Min Ratio	0CH
Microcode Revision	0200004D
L1 Cache RAM	64KB
L2 Cache RAM	1024KB
L3 Cache RAM	16896KB

Processor 0 Version Intel(R) Core(TM) i9-79

00X CPU @ 3.30GHz

Hyper-Threading [ALL]
Enables Hyper-Threading (Software Method to Enable/Disable Logical Processor threads).

VMX
Enables the Vanderpool Technology, takes effect after reboot.

Enable SMX
Enables Safer Mode Extensions.

Hardware Prefetcher
= MLC Streamer Prefetcher (MSR 1A4h Bit[0])

Adjacent Cache Prefetch
= MLC Spatial Prefetcher (MSR 1A4h Bit[1])


DCU Streamer Prefetcher
DCU streamer prefetcher is an L1 data cache prefetcher (MSR 1A4h [2]).

DCU IP Prefetcher
DCU IP prefetcher is an L1 data cache prefetcher (MSR 1A4h [3]).

AES-NI
Enable/disable AES-NI support


Parameter	Description
Processor Configuration	
Per-Socket Configuration	<p>Press [Enter] to configure advanced items.</p> <ul style="list-style-type: none"> ◆ CPU Socket 0 Configuration <ul style="list-style-type: none"> – Press [Enter] to configure advanced items. ◆ Core Disable Bitmap(Hex) (for CPU socket 0/1) <ul style="list-style-type: none"> – Number of Cores to enable. 0 means all cores. FFFFFFFF means to disable all cores. The maximum value depends on the number of CPUs available. Press the numeric keys to adjust desired values.
Processor ID / Processor Frequency / Processor Max Ratio / Processor Min Ratio / Microcode Revision / L1 Cache RAM / L2 Cache RAM / L3 Cache RAM / Processor 0 Version	Displays the technical specifications for the installed processor(s).
Hyper-Threading [All]	<p>The Hyper Threading Technology allows a single processor to execute two or more separate threads concurrently. When hyper-threading is enabled, multi-threaded software applications can execute their threads, thereby improving performance.</p> <p>Options available: Enable/Disable. Default setting is Enable.</p>
VMX (Vanderpool Technology)	<p>Enable/Disable the Vanderpool Technology. This will take effect after rebooting the system.</p> <p>Options available: Enable/Disable. Default setting is Enable.</p>
Enable SMX	<p>Enable/Disable the Secure Mode Extensions (SMX) support function.</p> <p>Options available: Enable/Disable. Default setting is Disable.</p>
Hardware Prefetcher	<p>Select whether to enable the speculative prefetch unit of the processor.</p> <p>Options available: Enable/Disable. Default setting is Disable.</p>
Adjacent Cache Prefetch	<p>When enabled, cache lines are fetched in pairs. When disabled, only the required cache line is fetched.</p> <p>Options available: Enable/Disable. Default setting is Enable.</p>
DCU Streamer Prefetcher	<p>Prefetches the next L1 data line based upon multiple loads in same cache line.</p> <p>Options available: Enable/Disable. Default setting is Enable.</p>
DCU IP Prefetcher	<p>Prefetches the next L1 Data line based upon sequential load history.</p> <p>Options available: Enable/Disable. Default setting is Enable.</p>
AES-NI	<p>Enable/Disable the AES-NI (Intel Advanced Encryption Standard New Instructions) support function.</p> <p>Options available: Enable/Disable. Default setting is Enable.</p>

5-3-3 Common RefCode Configuration



Parameter	Description
Common RefCode Configuration	
MMCFG Size	Selects MMCFG size. Options available: 64M, 128M, 256M, 512M, 1G, 2G. Default setting is 256M .
MMIO High Base	Selects the MMIO High Base setting. Options available: 56T, 40T, 24T, 16T, 4T, 1T. Default setting is 56T .
MMIO High Granularity Size	Selects the allocation size used to assign mmioh resources. Total mmioh space can be up to 32xgranularity. Per stack mmioh resource assignments are multiples of the granularity where 1 unit per stack is the default allocation. Options available: 1G, 4G, 16G, 64G, 256G, 1024G. Default setting is 256G .
Isoc Mode	Enable/Disable the Isochronous support in order to meet the QoS requirements (Quality of Service). Options available: Auto, Enable, Disable. Default setting is Auto .


5-3-4 Memory Configuration



Parameter	Description
Integrated Memory Controller (iMC)	
Enforce POR	When set to Enable, the system enforces Plan Of Record restrictions for DDR4 frequency and voltage programming. When set to Auto, the system sets it to the MRC default settings. Options available: Auto, POR, Disable. Default setting is Auto .
Enable ADR	Enables the detecting and enabling of ADR (Asynchronous DRAM Refresh) function. Options available: Enable/Disable. Default setting is Enable .
Legacy ADR Mode	Enable/Disable the Legacy ADR Mode. Options available: Enable/Disable. Default setting is Disable .
Memory Topology	Press [Enter] to view memory topology with DIMM population information.
Memory Map	Press [Enter] to configure advanced items. <ul style="list-style-type: none"> ◆ IMC Interleaving <ul style="list-style-type: none"> – controls the interleaving between the Integrated Memory Controllers (IMCs). – Options available: Auto, 1-way Interleave, 2-way Interleave. Default setting is Auto.

Parameter	Description
Memory RAS Configuration	<p>Press [Enter] to configure advanced items.</p> <ul style="list-style-type: none"> ◆ Static Virtual Lockstep Mode <ul style="list-style-type: none"> – Enable/Disable the Static Virtual Lockstep mode. – Options available: Disable/Enable. Default setting is Disable. ◆ Mirror Mode <ul style="list-style-type: none"> – Mirror Mode will set entire 1LM/2LM memory in system to be mirrored, consequently reducing the memory capacity by half. Enables the Mirror Mode will disable the XPT Prefetch. – Options available: Disable, Mirror Mode 1LM, Mirror Mode 2LM. Default setting is Disable. ◆ Correctable Error Threshold <ul style="list-style-type: none"> – Correctable Error Threshold (1-32767) used for sparing, tagging, and leaky bucket. – Press the <+> / <-> keys to increase or decrease the desired values.

5-3-5 IIO Configuration



Parameter	Description
IIO Configuration	<p>Press [Enter] to configure advanced items.</p> <ul style="list-style-type: none"> ◆ Intel® VT for Directed I/O (VT-d) <ul style="list-style-type: none"> – Enable/Disable the Intel VT for Directed I/O (VT-d) support function by reporting the I/O device assignment to VMM through DMAR ACPI Tables. – Options available: Enable/Disable. Default setting is Enable. ◆ Interrupt Remapping <ul style="list-style-type: none"> – Enable/Disable the interrupt remapping support function. – Options available: Enable/Disable. Default setting is Enable. ◆ PassThrough DMA <ul style="list-style-type: none"> – Enable/Disable the Non-Isoch VT_D Engine PassThrough DMA support function. – Options available: Enable/Disable. Default setting is Enable. ◆ ATS <ul style="list-style-type: none"> – Enable/Disable Non-Isoch VT_D Engine ATS support. – Options available: Enable/Disable. Default setting is Enable. ◆ Posted Interrupt <ul style="list-style-type: none"> – Enable/Disable VT_D posted interrupt. – Options available: Enable/Disable. Default setting is Enable. ◆ Coherency Support (Non-Isoch) <ul style="list-style-type: none"> – Enable/Disable Non-Isoch VT_D Engine Coherency support. – Options available: Enable/Disable. Default setting is Enable.
Intel® VT for Directed I/O (VT-d)	

Parameter	Description
Intel® VMD technology	<p data-bbox="388 148 718 172">Press [Enter] to configure advanced items.</p> <ul data-bbox="388 180 925 290" style="list-style-type: none"><li data-bbox="388 180 606 203">◆ Intel® VMD technology<li data-bbox="388 211 925 290">◆ Intel® VMD Configuration<ul data-bbox="425 235 925 290" style="list-style-type: none"><li data-bbox="425 235 813 258">– Enable/Disable the Intel VMD support function.<li data-bbox="425 266 925 290">– Options available: Enable/Disable. Default setting is Disable.

5-3-6 Advanced Power Management Configuraiton




Parameter	Description
Advanced Power Management Configuration	
CPU P State Control	<p>Press [Enter] to configure advanced items.</p> <ul style="list-style-type: none"> ◆ SpeedStep (Pstates) <ul style="list-style-type: none"> – Conventional Intel SpeedStep Technology switches both voltage and frequency in tandem between high and low levels in response to processor load. – Options available: Enable/Disable. Default setting is Enable. ◆ Turbo Mode <ul style="list-style-type: none"> – When this item is enabled, the processor will automatically ramp up the clock speed of 1-2 of its processing cores to improve its performance. When this item is disabled, the processor will not overclock any of its core. – Options available: Enable/Disable. Default setting is Enable.
Hardware PM State Control	<p>Press [Enter] to configure advanced items.</p> <ul style="list-style-type: none"> ◆ Hardware P-States <ul style="list-style-type: none"> – When this item is disabled, the processor hardware chooses a P-state based on OS Request (Legacy P-States). – In Native mode, the processor hardware chooses a P-state based on OS guidance. – In Out of Band mode, the processor hardware autonomously chooses a P-state (with no OS guidance). – Options available: Disable, Native Mode, Out of Band Mode, Native Mode with No Legacy Support. Default setting is Native Mode.

Parameter	Description
CPU C State Control	<p>Press [Enter] to configure advanced items.</p> <ul style="list-style-type: none"> ◆ Autonomous Core C-State <ul style="list-style-type: none"> – Enable/Disable the Autonomous Core C-State Control. – Options available: Enable/Disable. Default setting is Disable. ◆ CPU C6 Report <ul style="list-style-type: none"> – Allows you to determine whether to let the CPU enter C6 mode in system halt state. When enabled, the CPU core frequency and voltage will be reduced during system halt state to decrease power consumption. The C6 state is a more enhanced power-saving state than C1. – Options available: Disable/Enable/Auto. Default setting is Auto. ◆ Enhanced Halt State (C1E)^(Note) <ul style="list-style-type: none"> – Core C1E auto promotion control. Takes effect after reboot. – Options available: Enable/Disable. Default setting is Enable.
Package C State Control	<p>Configures the state for the C-State package limit.</p> <p>Options available: C0/C1 state, C2 state, C6(non Retention) state, C6(Retention) state, No Limit, Auto.</p> <p>Default setting is Auto.</p>

(Note) Advanced items prompt when this item is defined.

5-3-7 Miscellaneous Configuration



Parameter	Description
Miscellaneous Configuration	
BIOS Guard	Enable/Disable BIOS Guard Platform Protection Technology. Options available: Enabled/Disabled. Default setting is Disabled .
Flash Wear Out Protection	Enable/Disable the function to protect the flash part from malicious writes intended to wear it out. Options available: Enabled/Disabled. Default setting is Disabled .
Active Video	Selects active video type. Options available: Auto, Onboard Device, PCIE Device. Default setting is Auto .

5-3-8 Runtime Error Logging

The image shows three panels of the BIOS Setup interface, each with a left-hand navigation menu and a main content area.

Panel 1: System Event Log

- Main** (Home icon)
- Advanced** (Clipboard icon)
- Chipset** (Chipset icon) - **Selected**
- OC Config** (List icon)
- Server Mgmt** (List icon)
- Security** (Lock icon)
- Boot** (Refresh icon)
- Save & Exit** (Save icon)

System Event Log

- System Errors** (Enable) (Dropdown arrow)

System Error Enable/Disable setup options.

- S/W Error Injection Support** (Disable) (Dropdown arrow)

When Enabled S/W Error Injection is supported by unlocking MSR 0x790

- System Memory Poison** (Enable) (Dropdown arrow)

Enable/Disable System Memory Poison

- Viral Status** (Enable) (Dropdown arrow)

Enable/Disable Viral

- Clear Viral Status** (Disable) (Dropdown arrow)

Enable/Disable Clear Viral Status

- System Cloaking** (Disable) (Dropdown arrow)

When enabled, Corrected and UCNA errors are masked from OS/SW visibility

Panel 2: Advanced Chipset settings

- Advanced** (Clipboard icon)
- Chipset** (Chipset icon) - **Selected**
- OC Config** (List icon)
- Server Mgmt** (List icon)
- Security** (Lock icon)
- Boot** (Refresh icon)
- Save & Exit** (Save icon)

UboxToPcuMca Enabling (Enable) (Dropdown arrow)

Enables or disables Ubox Local errors to cause MCA.

CATERR->GPIO->SMI (Disable) (Dropdown arrow)

Enable/Disable PCH GPIO to trigger SMI on CATERR

FatalErrDebugHalt (Disable) (Dropdown arrow)

DEBUG loop for McBank Fatal error case ONLY. Warning: Enable this knob only in conjunction with ITP as thread will halt in Fatal error flow

eMCA Settings

Press <Enter> to view or change the eMCA configuration.

Error Injection Settings

Press <Enter> to view or change the Error Injection configuration.

Memory Error Enabling

Press <Enter> to view or change the Memory errors enabling options.

Panel 3: Boot settings

- Boot** (Refresh icon)
- Save & Exit** (Save icon)

IIO Error Enabling

Press <Enter> to view or change the IIO errors enabling options.

PCIe Error Enabling


Press <Enter> to view or change the PCIe errors enabling options.

Platform Level Error Enabling (Selected)

Press <Enter> to view or change the Platform Level errors enabling options.


Parameter	Description
System Event Log	
System Errors	Enable/Disable system error logging function. Options available: Enable/Disable. Default setting is Enable .
S/W Error Injection Support	When enabled, software error injection is supported by unlocking MSR 0x790. Options available: Enable/Disable. Default setting is Disable .
System Memory Poison	Enable/Disable system memory poison function. Options available: Enable/Disable. Default setting is Enable .
Viral Status	Enable/Disable viral function. Options available: Enable/Disable. Default setting is Enable .
Clear Viral Status	Enable/Disable clear viral function. Options available: Enable/Disable. Default setting is Disable .
System Cloaking	When Enabled system cloaking function, corrected and UCNA errors are masked from OS/SW visibility. Options available: Enable/Disable. Default setting is Disable .
UboxToPcuMca Enabling	Enable/Disable system to report Ubox local errors to MCA. Options available: Enable/Disable. Default setting is Enable .
CATERR->GPIO->SMI	Enable/Disable PCH GPIO to trigger SMI on CATERR. Options available: Enable/Disable. Default setting is Disable .
FatalErrDebugHalt	Debug loop for McBank Fatal error case ONLY. Warning: Enable this knob only in conjunction with ITP as thread will halt in Fatal error flow. Options available: Enable/Disable. Default setting is Disable .
eMCA Settings	Press [Enter] to view or configure advanced items.
Error Injection Settings	Press [Enter] to view or configure advanced items.
Memory Error Enabling	Press [Enter] to view or configure advanced items.
IIO Error Enabling	Press [Enter] to view or configure advanced items.
PCIe Error Enabling	Press [Enter] to view or configure advanced items.
Platform Level Error Enabling	Press [Enter] to view or configure advanced items.

5-3-8-1 eMCA Settings



Parameter	Description
eMCA Settings	
EMCA Logging Support	Enable/Disable EMCA logging function. Options available: Enable/Disable. Default setting is Enable .
LMCE Support	Enable/Disable Local MCE firmware support. Options available: Enable/Disable. Default setting is Enable .
Ignore OS EMCA Opt-in	Enable/Disable Ignore OS EMCA Opt-in and log feature. Options available: Enable/Disable. Default setting is Disable .
EMCA CMCI-SMI Morphing	Enable/Disable EMCA CSMI support. Options available: Disable, EMCA gen1 Lite, EMCA gen2 CSMI. Default setting is EMCA gen2 CSMI .
EMCA MCE-SMI Enable	Enable/Disable EMCA Uncorrected SMI for gen1 and gen2. Options available: Disable, EMCA gen1 Dual Mode, EMCA gen2-MSMI. Default setting is EMCA gen2-MSMI .
Corrected Error eLog	Enable/Disable corrected error eLog feature. Options available: Enable/Disable. Default setting is Enable .
Processor Error eLog	Enable/Disable processor error eLog feature. Options available: Enable/Disable. Default setting is Enable .


5-3-8-2 Error Injection Settings



Parameter	Description
Error Injection Settings	
Mca Bank Error Injection Support	Enable/Disable Mca Bank Error Injection Support. Options available: Enable/Disable. Default setting is Disable .
WHEA Error Injection Support	Enable/Disable WHEA Error Injection support. Please disable DIRECTORY MODE for memory error injection. Options available: Enable/Disable. Default setting is Enable .
EHEA Error Injection 5.0 Extension	Enable/Disable Whea EINJ ACPI 5.0 support for set error type with address and vendor extensions. Options available: Enable/Disable. Default setting is Enable .
Whea PCIe Error Injection support	Enable/Disable Whea PCIe Error Injection support. Options available: Enable/Disable. Default setting is Enable .
Whea PCIe Error Injection Action Table	Enable/Disable Whea PCIe Error Injection Action Table. Options available: Enable/Disable. Default setting is Enable .

Parameter	Description
ME Seg Error Injection Support	Enable/Disable ME Seg Error Injection Support. Options available: Enable/Disable. Default setting is Disable .
Enable HA Parity Check	Enable/Disable HA Parity Check feature. Options available: Enable/Disable. Default setting is Disable .
Mca Bank Warm Boot Clear Errors	Enable/Disable Mca Bank Warm Boot Clear Errors feature. Options available: Enable/Disable. Default setting is Disable .

5-3-8-3 Memory Error Enabling



Parameter	Description
Memory Error Enabling	
Memory Error	Enable/Disable Memory Error. Options available: Enable/Disable. Default setting is Enable .
Memory Corrected Error	Enable/Disable Memory Corrected Error. Options available: Enable/Disable. Default setting is Enable .
Memory Leaky Bucket Value	Sets Memory Leaky Bucket Value. (0x0000 - 0xffff)
Spare Interrupt	Selects Spare Interrupt type. Options available: Disable, SMI, Error Pin, CMCI. Default setting is Disable .
NVMCTLR Errors	Enable/Disable NVMCTLR Errors Reporting and Logging. Options available: Enable/Disable. Default setting is Disable .
NVMCTLR Low Priority Error Signaling	Specifies the NVMCTLR low priority signaling. Options available: Disable, SMI, ERRO# Pin. Default setting is Disable .
NVMCTLR High Priority Error Signaling	Specifies the NVMCTLR high priority signaling. Options available: Disable, SMI, ERRO# Pin. Default setting is Disable .

Parameter	Description
CLR/Ring ^(Note)	<p>Press [Enter] to configure advanced items.</p> <ul style="list-style-type: none"> ◆ CLR Max OC Ratio <ul style="list-style-type: none"> – Sets the maximum OC Ratio for the CLR Domain. ◆ CLR Min Ratio <ul style="list-style-type: none"> – Sets the minimum ratio for the CLR Domain. ◆ CLR Voltage Mode <ul style="list-style-type: none"> – In Override mode, the voltage selected will be applied over all operating frequencies. – In Adaptive mode, the voltage is interpolated only in turbo mode. – Options available: Adaptive/Override. Default setting is Adaptive. ◆ CLR Extra Turbo Voltage <ul style="list-style-type: none"> – Specifies the extra turbo voltage applied while GT is operating in millivolts. Range 0-2000 mV. ◆ CLR Voltage Offset <ul style="list-style-type: none"> – Specifies the Offset voltage applied to GT domain. This voltage is specified in millivolts. Range -1000 to 1000 mV. ◆ Offset Prefix <ul style="list-style-type: none"> – Sets the offset value as positive or negative.
Uncore ^(Note)	<p>Press [Enter] to configure advanced items.</p> <ul style="list-style-type: none"> ◆ Uncore Voltage Offset <ul style="list-style-type: none"> – Specifies the Offset voltage applied to the Uncore domain. This voltage is specified in millivolts. Range -1000 to 1000 mV. ◆ Offset Prefix <ul style="list-style-type: none"> – Sets the offset value as positive or negative.
SVID/FIVR ^(Note)	<p>Press [Enter] to configure advanced items.</p> <ul style="list-style-type: none"> ◆ VCCIN <ul style="list-style-type: none"> – Enable/Disable VCCIN through external VR. – Options available: Enable/Disable. Default setting is Disable. ◆ FIVR Faults <ul style="list-style-type: none"> – Enable/Disable FIVR faults. When this function are disabled, OVP and OCP protection mechanisms will be masked. This is a dangerous configuration and the risk of using it is assumed by the user. – Options available: Enable/Disable. Default setting is Enable. ◆ FIVR Efficiency Management <ul style="list-style-type: none"> – FIVR efficiency management is good for power delivery efficiency, but it may be an impediment to proper power delivery control under overclocking, particularly BCLK overclocking. – Options available: Enable/Disable. Default setting is Enable.
TJ-Max offset ^(Note)	Changes the TJ-Max offset (125°C - fuse value).

(Note) This item appears when **OverClocking Feature** is set to **Enabled**.


5-3-8-4 IIO Error Enabling

IIO Error Enabling

- IIO/PCH Global Error Support: Enable
- IIO MCA Support: Disable
- IIO Error Pin Programming: Disable
- IIO Error Registers Clear: Enable
- IIO LER Support: Disable
- IIO Coherent Interface Error: Enable

- IIO IRP0 protocol parity error: Enable
- IIO IRP0 protocol qt overflow underflow error: Enable
- IIO IRP0 protocol rcvd unexprsp: Enable
- IIO IRP0 csr acc 32b unaligned: Enable
- IIO IRP0 wrcache uncorrects0 error: Enable



- IIO IRP0 wrcache uncorrects1 error: Enable
- IIO IRP0 protocol rcvd poison error: Enable
- IIO IRP0 wrcache corrects0 error: Enable
- IIO IRP0 wrcache corrects1 error: Enable
- IIO Misc. Error: Enable



Parameter	Description
IIO Error Enabling	
IIO/PCH Global Error Support	Enable/Disable IIO/PCH Error Support. Options available: Enable/Disable. Default setting is Enable .
IIO MCA Support	Enable/Disable IIO MCA Support. Options available: Enable/Disable. Default setting is Disable .
IIO Error Pin Programming	Enable/Disable IIO Error Pin Programming. Options available: Enable/Disable. Default setting is Disable .
IIO Error Registers Clear	Enable/Disable clearing IIO Error registers. Options available: Enable/Disable. Default setting is Enable .
IIO LER Support	Enable/Disable IIO LER Support. Options available: Enable/Disable. Default setting is Disable .
IIO Coherent Interface Error	Enable/Disable IIO Coherent Interface Error. Options available: Enable/Disable. Default setting is Enable .
IIO IRP0 protocol parity error	Enable/Disable Coherent Interface protocol IIO parity error reporting. Options available: Enable/Disable. Default setting is Enable .
IIO IRP0 protocol qt overflow underflow error	Enable/Disable IIO Coherent Interface protocol queue table overflow or underflow error reporting. Options available: Enable/Disable. Default setting is Enable .
IIO IRP0 protocol rcvd unexprsp	Enable/Disable IIO Coherent Interface protocol layer received unexpected response or completion error reporting. Options available: Enable/Disable. Default setting is Enable .
IIO IRP0 csr acc 32b unaligned	Enable/Disable IIO Coherent Interface CSR Access Crossing 32-bit Boundary error reporting. Options available: Enable/Disable. Default setting is Enable .

Parameter	Description
IIO IRP0 wrccache uncecccs0 error	Enable/Disable IIO Coherent Interface Write Cache Un-correctable ECC error reporting. Options available: Enable/Disable. Default setting is Enable .
IIO IRP0 wrccache uncecccs1 error	Enable/Disable IIO Coherent Interface Write Cache Un-correctable ECC error reporting. Options available: Enable/Disable. Default setting is Enable .
IIO IRP0 protocol rcvd poison error	Enable/Disable IIO Coherent Interface protocol layer received poisoned packet error reporting. Options available: Enable/Disable. Default setting is Enable .
IIO IRP0 wrccache correcccs0 error	Enable/Disable IIO Coherent Interface Write Cache Correctable ECC error reporting. Options available: Enable/Disable. Default setting is Enable .
IIO IRP0 wrccache correcccs1 error	Enable/Disable IIO Coherent Interface Write Cache Correctable ECC error reporting. Options available: Enable/Disable. Default setting is Enable .
IIO Misc. Error	Enable/Disable IIO Misc. Error. Options available: Enable/Disable. Default setting is Enable .
IIO Vtd Error	Enable/Disable IIO Vtd Error. Options available: Enable/Disable. Default setting is Enable .
IIO Dma Error	Enable/Disable IIO DMA Error. Options available: Enable/Disable. Default setting is Enable .
IIO Dmi Error	Enable/Disable IIO DMI Error. Options available: Enable/Disable. Default setting is Disable .
PCIe Error	Enable/Disable PCIe Error. Options available: Enable/Disable. Default setting is Enable .
IIO PCIe Additional Corrected Error	Enable/Disable IIO PCIe additional corrected error. Options available: Enable/Disable. Default setting is Enable .
IIO PCIe Additional Uncorrected Error	Enable/Disable IIO PCIe additional uncorrected error. Options available: Enable/Disable. Default setting is Enable .
IIO PCIe AER Spec Compliant	Enable/Disable IIO PCIe AER(Advanced Error Reporting) Spec compliant. Options available: Enable/Disable. Default setting is Disable .

5-3-8-5 PCIe Error Enabling




Parameter	Description
PCIe Error Enabling	
Corrected Error	Enables and escalates Correctable Errors to error pins. Options available: Enable/Disable. Default setting is Enable .
Uncorrected Error	Enables and escalates Uncorrectable/Recoverable Errors to error pins. Options available: Enable/Disable. Default setting is Enable .
Fatal Error Enable	Enables and escalates Fatal Errors to error pins. Options available: Enable/Disable. Default setting is Enable .
PCIe Corrected Error Threshold Counter	Enable/Disable PCIe corrected error counter. Options available: Enable/Disable. Default setting is Disable .

Parameter	Description
PCIe Corrected Error Threshold	Configures PCIe corrected error threshold. (0x001 - 0xffff)
PCIe AER Corrected Errors	Enable/Disable PCIe AER corrected error. Options available: Enable/Disable. Default setting is Enable .
PCIe AER Advisory Nonfatal Error	Enable/Disable PCIe AER nonfatal error. Options available: Enable/Disable. Default setting is Enable .
PCIe AER Fatal Error	Enable/Disable PCIe AER fatal error. Options available: Enable/Disable. Default setting is Enable .
SERR Propagation	Enable/Disable SERR propagation. Options available: Enable/Disable. Default setting is Enable .
PERR Propagation	Enable/Disable PERR propagation. Options available: Enable/Disable. Default setting is Enable .
Signal to OS on SERR	Enable/Disable Signal to OS on SERR. Options available: Enable/Disable. Default setting is Enable .
Signal to OS on PERR	Enable/Disable Signal to OS on PERR. Options available: Enable/Disable. Default setting is Enable .



5-4 OC Configuration Menu

OC Configuration menu displays submenu options for configuring the function of Processor OverClocking, Memory OverClocking, Voltage Setting and Power & Performance.

Select a submenu item, then press <Enter> to access the related submenu screen.



5-4-1 Processor OverClocking




Parameter	Description
OverClocking	
OverClocking Feature	Enable/Disable OverClocking feature. Options available: Enable/Disable. Default setting is Disable .
WDT Enable	Enable/Disable WatchDog Timer. Note: This option is ignored on debug BIOS. Options available: Enable/Disable. Default setting is Enable .
Processor ^(Note)	<p>Press [Enter] to configure advanced items.</p> <ul style="list-style-type: none"> ◆ CPU Mode <ul style="list-style-type: none"> – Options available: All core/Per core. Default setting is All core. ◆ Core Max OC Ratio <ul style="list-style-type: none"> – Sets the maximum OC Ratio for the CPU core. Range 0-80. ◆ Core Voltage Mode <ul style="list-style-type: none"> – In Override mode, the voltage selected will be applied over all operating frequencies. – In Adaptive mode, the voltage is interpolated only in turbo mode. – Options available: Adaptive/Override. Default setting is Adaptive. ◆ Core Extra Turbo Voltage <ul style="list-style-type: none"> – Specifies the extra turbo voltage applied while IA core is operating in turbo mode. Range 0-2000 mV. ◆ Core Voltage Offset <ul style="list-style-type: none"> – Specifies the Offset voltage applied to IA core domain. This voltage is specified in millivolts. Range -500 to 500 mV. ◆ Offset Prefix <ul style="list-style-type: none"> – Sets the offset value as positive or negative. ◆ AVX2 Negative Offset <ul style="list-style-type: none"> – AVX2 Negative Offset applied by Pcode OC mailbox read(0x1A)/Write(0x1B). ◆ AVX3 Negative Offset <ul style="list-style-type: none"> – AVX3 Negative Offset applied by Pcode OC mailbox read(0x1A)/Write(0x1B). ◆ BCLK Setting <ul style="list-style-type: none"> – Options available: 1, 2, 3, 4, 5, 6, 7. Default setting is 7.

(Note) This item appears when **OverClocking Feature** is set to **Enabled**.

Parameter	Description
Adjust PII ^(Note)	Enable/Disable Adjust PII Value - send the mailbox command to adjust the PII for Higher-BCLK Ratio combination. Options available: Enable/Disable. Default setting is Disable .
Change PIITrim Value ^(Note)	Changes PII Value between +63 to -63.
Change PLLTRIM Prefix ^(Note)	Changes PLLTRIM Prefix to + or -.
Change MC-PIITrim Value ^(Note)	Changes MC-PII Value between +63 to -63.
Change MC-PIITrim Prefix ^(Note)	Changes MC-PLLTRIM Prefix to + or -.
DCST-LUT ^(Note)	Enable/Disable DCST-LUT feature. Options available: Enable/Disable. Default setting is Enable .
Dcst-Value ^(Note)	Configures the DCST-LUT values byte def for LUT0 [3:0] LUT1 [11:8] LUT2 [19:16] LUT3 [27:24].


(Note) This item appears when **OverClocking Feature** is set to **Enabled**.

5-4-2 Memory OverClocking



Parameter	Description
Memory Frequency	Configures the maximum memory frequency. Default setting is Auto .
IMC BCLK	Configures IMC BCLK. Default setting is Auto .
XMP Profile	Selects the XMP profile to use. Options available: Disable, Manual, Profile1. Default setting is Disable .


5-4-3 Voltage Setting



Parameter	Description
CPU VR Loadline	Configures CPU VR Loadline. Options available: Auto, Level 1, Level 2, Level 3. Default setting is Auto .
SVID Support	Enable/Disable SVID support to input voltage overrides. Options available: Enabled/Disabled. Default setting is Enabled .
SVID VCCIN Voltage Override	Sets a value (0~2500 mV) for overriding the VccIN input voltage. This controls the input voltage to the CPU and will affect all CPU domains. Default setting is 0 .
SVID VCCSA Voltage Override	Sets a value (0~2500 mV) for overriding the VccSA input voltage. This controls the input voltage to the CPU and will affect all CPU domains. Default setting is 0 .
SVID VCCIO Voltage Override	Sets a value (0~2500 mV) for overriding the VccIO input voltage. This controls the input voltage to the CPU and will affect all CPU domains. Default setting is 0 .
VPP_AB Voltage	Configures the settings of VPP_AB Voltage.
VDDQ_AB Voltage	Configures the settings of VDDQ_AB Voltage.
VPP_CD Voltage	Configures the settings of VPP_CD Voltage.


Parameter	Description
VDDQ_CD Voltage	Configures the settings of VDDQ_CD Voltage.
VR Power Limit	Configures VR Power Limit. Options available: Locked/Unlocked. Default setting is Locked .

5-4-4 Power & Performance



Parameter	Description
Power & Performance	
CPU-Power Management Control	Press [Enter] to configure advanced items.
PL1 Power Limit	Configures PL1 Power Limit in Watts. The value may vary from 0 to fused value. If the value is 0, the fused value will be programmed. A value greater than fused TDP value will not be programmed.
PL2 Power Limit	Configures PL2 Power Limit in Watts. The value may vary from 0 to fused value. If the value is 0, BIOS programs 120% * TDP.

5-4-4-1 CPU-Power Management Control




Parameter	Description
CPU-Power Management Control	
Boot performance mode	Selects the performance state that the BIOS will set starting from reset vector. Options available: Max Battery, Max Non-Turbo Performance, Turbo Performance. Default setting is Max Non-Turbo Performance .
Race To Halt (RTH)	Enable/Disable Race to Halt feature. RTH will dynamically increase CPU frequency in order to enter pkg C-state faster to reduce overall power. (RTH is controlled through MSR 1FC bit 20) Options available: Enabled/Disabled. Default setting is Enabled .
HDC Control	Enable/Disable HDC configuration. Options available: Enabled/Disabled. Default setting is Enabled .

Parameter	Description
View/Configure Turbo Options	<p data-bbox="419 158 777 180">Press [Enter] to view/configure Turbo Options.</p> <ul style="list-style-type: none"> <li data-bbox="419 189 948 294">◆ Energy Efficient P-state <ul style="list-style-type: none"> <li data-bbox="455 216 852 238">– Enable/Disable Energy Efficient P-state feature. <li data-bbox="455 244 948 294">– Options available: Enabled/Disabled. Default setting is Enabled. <li data-bbox="419 304 948 471">◆ Package Power Limit MSR Lock <ul style="list-style-type: none"> <li data-bbox="455 330 948 413">– Enable/Disable locking of package power limit settings. When enabled, PACKAGE_POWER_LIMIT MSR will be locked and a reset will be required to unlock the register. <li data-bbox="455 420 948 471">– Options available: Enabled/Disabled. Default setting is Disabled. <li data-bbox="419 481 948 649">◆ PL1 Limit <ul style="list-style-type: none"> <li data-bbox="455 508 948 591">– Enable/Disable PL1 limit feature. If this option is disabled, BIOS will program the default values for PL1 Power Limit and PL1 Time Window. <li data-bbox="455 597 948 649">– Options available: Enabled/Disabled. Default setting is Disabled. <li data-bbox="419 658 948 794">◆ PL1 Power Limit <ul style="list-style-type: none"> <li data-bbox="455 685 948 794">– Configures PL1 power limit in Watts. The value may vary from 0 to fused value. If the value is 0, the fused value will be programmed. A value greater than fused TDP value will not be programmed. <li data-bbox="419 804 948 940">◆ PL1 Time Window <ul style="list-style-type: none"> <li data-bbox="455 831 948 940">– Configures PL1 value in seconds. The value may vary from 0 to 56. Indicated the time window over which TDP value should be maintained. if the value is 0, the fused value will be programmed. <li data-bbox="419 950 948 1117">◆ Power Limit 2 Override <ul style="list-style-type: none"> <li data-bbox="455 976 948 1059">– Enable/Disable power limit 2 override. If this option is disabled, BIOS will program the default values for Power Limit 2. <li data-bbox="455 1066 948 1117">– Options available: Enabled/Disabled. Default setting is Enabled. <li data-bbox="419 1127 948 1232">◆ Power Limit 2 <ul style="list-style-type: none"> <li data-bbox="455 1154 948 1232">– Configures PL2 power limit in Watts. The value may vary from 0 to fused value. If the value is 0, BIOS programs 120% * TDP. <li data-bbox="419 1241 948 1378">◆ #1/2/3/4-Core Ratio Limit Override <ul style="list-style-type: none"> <li data-bbox="455 1268 948 1320">– Configures #-Core Ratio Limit with range 0 to 83. The minimum rang may vary between processors. <li data-bbox="455 1326 948 1378">– The 1-Core Ratio Limit must be greater than or equal to 2-Core Ratio Limit, 3-Core Ratio Limit, 4-Core Ratio Limit.

Parameter	Description
View/Configure Turbo Options (continued)	<ul style="list-style-type: none"> ◆ Energy Efficient Turbo <ul style="list-style-type: none"> – Enable/Disable Energy Efficient Turbo feature. This feature will opportunistically lower the turbo frequency to increase efficiency. Recommended only to disable in overclocking situations where turbo frequency must remain constant. Otherwise, leave enabled. – Options available: Enabled/Disabled. Default setting is Enabled.
CPU VR Settings	Press [Enter] to configure advanced items.
Platform PL1 Enable	<p>Enable/Disable Platform Power Limit 1 programming. If this item is enabled, it will activate the PL1 value to be used by the processor to limit the average power of given time window.</p> <p>Options available: Enabled/Disabled. Default setting is Disabled.</p>
Platform PL2 Enable	<p>Enable/Disable Platform Power Limit 2 programming. If this item is disabled, BIOS will program the default values for Platform Power Limit 2.</p> <p>Options available: Enabled/Disabled. Default setting is Disabled.</p>
Power Limit 4 Override	<p>Enable/Disable Power Limit 4 override, If this item is disabled, BIOS will leave the default values for Power Limit 4.</p> <p>Options available: Enabled/Disabled. Default setting is Disabled.</p>

5-4-4-1-1 CPU VR Setting



Parameter	Description
CPU VR Settings	
PSYS Slope	Sets a value for PSYS Slope which is defined in 1/100 increments. The Range is 0-200. Default setting is 0.
PSYS Offset	Sets a value for PSYS Offset which is defined in 1/4 increments. The Range is 0-255. Default setting is 0.
PSYS PMax Power	Sets a value for PSYS PMax power which is defined in 1/8 Watt increments. The Range is 0-8192. Default setting is 0.
Acoustic Noise Settings	<p>Press [Enter] to configure advanced items.</p> <ul style="list-style-type: none"> ◆ Acoustic Noise Mitigation <ul style="list-style-type: none"> – Enable/Disable this item to help mitigate acoustic noise on certain SKUs when the CPU is in deeper C state. – Options available: Enabled/Disabled. Default setting is Disabled. ◆ IA/GT/SA VR Domain^(Note) ◆ Disable Fast PKG C State Ramp for IA/GT/SA Domain^(Note) <ul style="list-style-type: none"> – This option needs to be configured to reduce acoustic noise during deeper C states. – Options available: TRUE/FALSE. Default setting is FALSE.


(Note) This item is available when **Acoustic Noise Mitigation** is set to **Enabled**.

Parameter	Description
Acoustic Noise Settings (continued)	<ul style="list-style-type: none"> ◆ Slow Slew Rate for IA/GT/SA Domain^(Note) <ul style="list-style-type: none"> – Sets VR IA/GT/SA Slow Slew Rate for Deep Package C State ramp time. Slow slew rate equals to Fast divided by number 2, 4, 8, 16. – Options available: Fast/2, Fast/4, Fast/8, Fast/16. Default setting is Fast/2.
System Agent VR Settings/ Core/IA VR Settings/ GT-UnSliced VR Settings/ GT-Sliced VR Settings	<p>Press [Enter] to configure advanced items.</p> <ul style="list-style-type: none"> ◆ VR Config Enable <ul style="list-style-type: none"> – Enable/Disable VR Configuration. – Options available: Enabled/Disabled. Default setting is Enabled. ◆ AC Loadline <ul style="list-style-type: none"> – Sets a value for AC Loadline which is defined in 1/100 mOhms. A value of 100 equals 1.0 mOhm, and 1255 is 12.55mOhms. The range is 0-6249 (0-62.49 mOhms). Default setting is 0. ◆ DC Loadline <ul style="list-style-type: none"> – Sets a value for DC Loadline which is defined in 1/100 mOhms. A value of 100 equals 1.0 mOhm, and 1255 is 12.55mOhms. The range is 0-6249 (0-62.49 mOhms). Default setting is 0. ◆ PS Current Threshold1 <ul style="list-style-type: none"> – Sets a value for PS Current Threshold1 which is defined in 1/4A increments. A value of 400 equals 100A. The range is 0-512 which translates to 0-128A. Default setting is 80 for 20A. ◆ PS Current Threshold2 <ul style="list-style-type: none"> – Sets a value for PS Current Threshold2 which is defined in 1/4A increments. A value of 400 equals 100A. The range is 0-512 which translates to 0-128A. Default setting is 20 for 5A. ◆ PS Current Threshold3 <ul style="list-style-type: none"> – Sets a value for PS Current Threshold3 which is defined in 1/4A increments. A value of 400 equals 100A. The range is 0-512 which translates to 0-128A. Default setting is 4 for 1A. ◆ PS3 Enable <ul style="list-style-type: none"> – Enable/Disable PS3. – Options available: Enabled/Disabled. Default setting is Enabled.

(Note) This item is available when **Acoustic Noise Mitigation** is set to **Enabled**.

Parameter	Description
System Agent VR Settings/ Core/IA VR Settings/ GT-UnSliced VR Settings/ GT-Sliced VR Settings (continued)	<ul style="list-style-type: none"> ◆ PS4 Enable <ul style="list-style-type: none"> – Enable/Disable PS4. – Options available: Enabled/Disabled. Default setting is Enabled. ◆ IMON Slope <ul style="list-style-type: none"> – Sets a value for IMON Slope which is defined in 1/100 increments. The range is 0-200. Default setting is 0. ◆ IMON Offset <ul style="list-style-type: none"> – Sets a value for IMON Offset which is defined in 1/1000 increments. The range is 0-63999. Default setting is 0. ◆ IMON Prefix <ul style="list-style-type: none"> – Sets the offset value as positive or negative. ◆ VR Current Limit <ul style="list-style-type: none"> – Sets a value for Voltage Regulator Current Limit. The value represents the maximum instantaneous current allowed at any given time. The value is represented in 1/4A (Ampere) increments. A value of 400 equals 100A. Default setting is 0. ◆ VR Voltage Limit <ul style="list-style-type: none"> – Sets a value for VR Voltage Limit which is defined in mV. The range is 0-7999mV, Default setting is 0. ◆ TDC Enable <ul style="list-style-type: none"> – Enable/Disable TDC. – Options available: Enabled/Disabled. Default setting is Enabled. ◆ TDC Current Limit <ul style="list-style-type: none"> – Sets a value for TDC current Limit which is defined in 1/8A increments. The range is 0-32767. Default setting is 0. ◆ TDC Time Window <ul style="list-style-type: none"> – Options available: 1ms, 2ms, 3ms, 4ms, 5ms, 6ms, 7ms, 8ms, 9ms, 10ms. Default setting is 1ms. ◆ TDC Lock <ul style="list-style-type: none"> – Enable/Disable TDC Lock. – Options available: Enabled/Disabled. Default setting is Disabled.
VR Mailbox Command options	VR mailbox commands to send, 1:MPS VR cmd, 2:PS4 Exit VR cmd, 4:MPS VR Decay cmd. It can select multiple commands by entering sum of values of each command.


5-5 Server Management Menu



Parameter	Description
FRB-2 Timer	Enable/Disable FRB-2 timer (POST timer). Options available: Enabled/Disabled. Default setting is Disabled .
FRB-2 Timer timeout	Configure the FRB2 Timer timeout. Options available: 3 minutes/4 minutes/5 minutes/6 minutes. Default setting is 6 minutes . Please note that this item is configurable when FRB-2 Timer is set to Enabled.
FRB-2 Timer Policy	Configure the FRB2 Timer policy. Options available: Do Nothing/Reset/Power Down. Default setting is Do Nothing . Please note that this item is configurable when FRB-2 Timer is set to Enabled.
OS Watchdog Timer	Enable/Disable OS Watchdog Timer function. Options available: Enabled/Disabled. Default setting is Disabled .

Parameter	Description
OS Wtd Timer Timeout	Configure OS Watchdog Timer. Options available: 5 minutes, 10 minutes, 15 minutes, 20 minutes. Default setting is 5 minutes . Please note that this item is configurable when OS Watchdog Timer is set to Enabled.
OS Wtd Timer Policy	Configure OS Watchdog Timer Policy. Options available: Reset/Do Nothing/Power Down. Default setting is Reset . Please note that this item is configurable when OS Watchdog Timer is set to Enabled.
System Event Log	Press [Enter] to configure advanced items.
View FRU Information	Press [Enter] to view the advanced items.
BMC VLAN Configuration	Press [Enter] to view the advanced items.
BMC network configuration	Press [Enter] to configure advanced items.
IPv6 BMC Network Configuration	Press [Enter] to configure advanced items.


5-5-1 System Event Log



Parameter	Description
Enabling / Disabling Options	
SEL Components	Change this item to enable or disable all features of System Event Logging during boot. Options available: Enabled/Disabled. Default setting is Enabled .
Erasing Settings	
Erase SEL	Choose options for erasing SEL. Options available: No/Yes, On next reset/Yes, On every reset. Default setting is No .
When SEL is Full	Choose options for reactions to a full SEL. Options available: Do Nothing, Erase Immediately, Delete Oldest Record. Default setting is Do Nothing .
Custom EFI Logging Options	
Log EFI Status Codes	Enable/Disable the logging of EFI Status Codes (if not already converted to legacy). Options available: Disabled, Both, Error code, Progress code. Default setting is Error code .


5-5-2 View FRU Information

The FRU page is a simple display page for basic system ID information, as well as System product information. Items on this window are non-configurable.




(Note) The model name will vary depends on the product you purchased

5-5-3 BMC VLAN Configuration




Parameter	Description
BMC VLAN Configuration	
BMC VLAN ID	Select to configure BMC VLAN ID. The valid range is from 0 to 4094. When set to 0, BMC VLAN ID will be disabled.
BMC VLAN Priority	Select to configure BMC VLAN Priority. The valid range is from 0 to 7. When BMC VLAN ID is set to 0, BMC VLAN Priority will not be selected.

5-5-4 BMC Network Configuration



Parameter	Description
BMC network configuration	
Select NCSI and Dedicated LAN	Switch NCSI and dedicated LAN and send KCS command. Options available: Do Nothing, Mode1 (Dedicated), Mode2(NSCI), Mode3 (Failover). Default setting is Mode1 (Dedicated) .
Lan Channel 1	
Configuration Address source	Select to configure LAN channel parameters statically or dynamically (DHCP). Do nothing option will not modify any BMC network parameters during BIOS phase. Options available: Unspecified, Static, DynamicBmcDhcp. Default setting is DynamicBmcDhcp .
Station IP address	Displays IP Address information.
Subnet mask	Displays Subnet Mask information. Please note that the IP address must be in three digitals, for example, 192.168.000.001.
Router IP address	Displays the Router IP Address information.
Station MAC address	Displays the MAC Address information.
Real-time get BMC network address	Press [Enter] will set LAN mode and Address source and then get IP, Subnet, Gateway and MAC address.


5-5-5 IPv6 BMC Network Configuration



Parameter	Description
IPv6 BMC Network Configuration	
IPv6 BMC Lan Channel 1	
IPv6 BMC Lan Option	Enable/Disable IPv6 BMC LAN channel function. When this item is disabled, the system will not modify any BMC network during BIOS phase. Options available: Unspecified, Enable, Disable. Default setting is Enable .
IPv6 BMC Lan IP Address Source	Select to configure LAN channel parameters statically or dynamically (by BIOS or BMC). Options available: Unspecified, Static, Dynamic-Obtained by BMC running DHCP. Default setting is Dynamic-Obtained by BMC running DHCP .
IPv6 BMC Lan IP Address	Configures IPv6 BMC Lan IP Address.
IPv6 BMC Lan IP Prefix Length	Configures IPv6 BMC Lan IP Prefix Length.
IPv6 BMC Lan Default Gateway	Configures IPv6 BMC Lan Default Gateway

5-6 Security Menu

The Security menu allows you to safeguard and protect the system from unauthorized use by setting up access passwords.




There are two types of passwords that you can set:

- Administrator Password
Entering this password will allow the user to access and change all settings in the Setup Utility.
- User Password
Entering this password will restrict a user's access to the Setup menus. To enable or disable this field, a Administrator Password must first be set. A user can only access and modify the System Time, System Date, and Set User Password fields.

Parameter	Description
Administrator Password	Press [Enter] to configure the administrator password.
User Password	Press [Enter] to configure the user password.
Secure Boot	Press [Enter] to configure advanced items.

5-6-1 Secure Boot

The Secure Boot submenu is applicable when your device is installed the Windows® 8 (or above) operating system.



Parameter	Description
System Mode	Displays the system is in User mode or Setup mode.
Vendor Keys	Displays the Vendor Keys function is active or not active.
Secure Boot	Secure Boot activated when Platform Key (PK) is enrolled, System mode is User/Deployed, and CSM function is disabled. Options available: Enabled/Disabled. Default setting is Disabled .
Secure Boot Customization ^(Note)	Secure Boot requires all the applications that are running during the booting process to be pre-signed with valid digital certificates. This way, the system knows all the files being loaded before Windows loads and gets to the login screen have not been tampered with. When set to Standard, it will automatically load the Secure Boot keys from the BIOS databases. When set to Custom, you can customize the Secure Boot settings and manually load its keys from the BIOS database. Options available: Standard/Custom. Default setting is Custom.
Restore Factory Keys	Forces the system to user mode and installs factory default Secure Boot key database.
Reset To Setup Mode	Delete NVRAM content of all UEFI Secure Boot key databases.


(Note) Advanced items prompt when this item is set to **Custom**.

Parameter	Description
Key Management	<p data-bbox="334 153 666 169">Press [Enter] to configure advanced items.</p> <p data-bbox="334 185 937 232">Please note that this item is configurable when Secure Boot Mode is set to Custom.</p> <ul style="list-style-type: none"> <li data-bbox="334 239 944 341">◆ Factory Key Provision <ul style="list-style-type: none"> <li data-bbox="370 268 944 315">– Allows to provision factory default Secure Boot keys when system is in Setup Mode. <li data-bbox="370 323 900 341">– Options available: Enabled/Disabled. Default setting is Disabled. <li data-bbox="334 349 926 428">◆ Restore Factory Keys <ul style="list-style-type: none"> <li data-bbox="370 377 926 396">– Installs all factory default keys. It will force the system in User Mode. <li data-bbox="370 404 602 428">– Options available: Yes/No. <li data-bbox="334 435 889 482">◆ Reset To Setup Mode <ul style="list-style-type: none"> <li data-bbox="370 464 889 482">– Delete NVRAM content of all UEFI Secure Boot key databases. <li data-bbox="334 490 937 569">◆ Export Secure Boot variables <ul style="list-style-type: none"> <li data-bbox="370 519 937 569">– Copy NVRAM content of Secure Boot variables to files in a root folder on a file system device. <li data-bbox="334 577 902 655">◆ Enroll Efi Image <ul style="list-style-type: none"> <li data-bbox="370 605 902 655">– Press [Enter] to enroll SHA256 hash of the binary into Authorized Signature Database (db). <li data-bbox="334 663 538 678">◆ Device Guard Ready <li data-bbox="334 686 907 765">◆ Remove 'UEFI CA' from DB <ul style="list-style-type: none"> <li data-bbox="370 715 907 765">– Remove 'Microsoft UEFI CA' certificate from Authorized Signature database. <li data-bbox="334 773 729 820">◆ Restore DB defaults <ul style="list-style-type: none"> <li data-bbox="370 801 729 820">– Restore the DB variable to factory defaults. <li data-bbox="334 827 538 843">◆ Secure Boot variable <li data-bbox="334 851 801 961">◆ Platform Key (PK) <ul style="list-style-type: none"> <li data-bbox="370 879 801 898">– Displays the current status of the Platform Key (PK). <li data-bbox="370 906 678 925">– Press [Enter] to configure a new PK. <li data-bbox="370 932 609 961">– Options available: Set New. <li data-bbox="334 969 944 1102">◆ Key Exchange Keys (KEK) <ul style="list-style-type: none"> <li data-bbox="370 997 944 1016">– Displays the current status of the Key Exchange Key Database (KEK). <li data-bbox="370 1023 907 1070">– Press [Enter] to configure a new KEK or load additional KEK from storage devices. <li data-bbox="370 1078 678 1102">– Options available: Set New/Append. <li data-bbox="334 1110 907 1243">◆ Authorized Signatures (DB) <ul style="list-style-type: none"> <li data-bbox="370 1138 907 1157">– Displays the current status of the Authorized Signature Database. <li data-bbox="370 1165 944 1212">– Press [Enter] to configure a new DB or load additional DB from storage devices. <li data-bbox="370 1219 678 1243">– Options available: Set New/Append. <li data-bbox="334 1251 902 1376">◆ Forbidden Signatures (DBX) <ul style="list-style-type: none"> <li data-bbox="370 1279 902 1298">– Displays the current status of the Forbidden Signature Database. <li data-bbox="370 1306 894 1353">– Press [Enter] to configure a new dbx or load additional dbx from storage devices. <li data-bbox="370 1361 678 1376">– Options available: Set New/Append.

Parameter	Description
Key Management (continued)	<ul style="list-style-type: none">◆ Authorized TimeStamps (DBT)<ul style="list-style-type: none">– Displays the current status of the Authorized TimeStamps Database.– Press [Enter] to configure a new DBT or load additional DBT from storage devices.– Options available: Set New/Append.◆ OsRecovery Signatures<ul style="list-style-type: none">– Displays the current status of the OsRecovery Signature Database.– Press [Enter] to configure a new OsRecovery Signature or load additional OsRecovery Signature from storage devices.– Options available: Set New/Append.

5-7 Boot Menu

The Boot menu allows you to set the drive priority during system boot-up. BIOS setup will display an error message if the legacy drive(s) specified is not bootable.




Parameter	Description
Boot Configuration	
Setup Prompt Timeout	Number of seconds to wait for setup activation key. 65535 (0xFFFF) means indefinite waiting. Press the numeric keys to input the desired values.
Bootup NumLock State	Enable/Disable the Bootup NumLock function. Options available: On/Off. Default setting is On .
Quiet Boot	Enable/Disable showing the logo during POST. Options available: Enabled/Disabled. Default setting is Enabled .
New Boot Option Policy	Controls the placement of newly detected UEFI boot options. Options available: Default, Place First, Place Last. Default setting is Default .

Parameter	Description
Boot mode select	Selects the boot mode. Options available: LEGACY/UEFI. Default setting is UEFI .
FIXED BOOT ORDER Priorities	
Boot Option #1 / #2 / #3 / #4 / #5	Press [Enter] to configure the boot priority. By default, the server searches for boot devices in the following sequence: <ul style="list-style-type: none"> 1. Hard drive. 2. CD-COM/DVD drive. 3. USB device. 4. Network. 5. UEFI.
UEFI Network Drive BBS Priorities	Press [Enter] to configure the boot device priority sequence from available UEFI network drives.
UEFI Application Boot Priorities	Press [Enter] to configure the boot device priority sequence from available UEFI application.

5-8 Save & Exit Menu

The Save & Exit menu displays the various options to quit from the BIOS setup. Highlight any of the exit options then press <Enter>.



Parameter	Description
Save Options	
Save Changes and Exit	Saves changes made and closes the BIOS setup. Options available: Yes/No.
Discard Changes and Exit	Discards changes made and exits the BIOS setup. Options available: Yes/No.
Save Changes and Reset	Restarts the system after saving the changes made. Options available: Yes/No.

Parameter	Description
Discard Changes and Reset	Restarts the system without saving any changes. Options available: Yes/No.
Save Changes	Saves changes made in the BIOS setup. Options available: Yes/No.
Discard Changes	Discards changes made and closes the BIOS setup. Options available: Yes/No.
Default Options	
Restore Defaults	Loads the default settings for all BIOS setup parameters. Setup Defaults are quite demanding in terms of resources consumption. If you are using low-speed memory chips or other kinds of low-performance components and you choose to load these settings, the system might not function properly. Options available: Yes/No.
Save as User Defaults	Saves the changes made as the user default settings. Options available: Yes/No.
Restore User Defaults	Loads the user default settings for all BIOS setup parameters. Options available: Yes/No.
Restore User Defaults 1 from USB	Restore the user defaults 1 to all the setup options from USB.
Boot Override	Press [Enter] to configure the device as the boot-up drive.

5-9 BIOS POST Codes

5-9-1 AMI Standard - PEI

PEI_CORE_STARTED	0x10
PEI_CAR_CPU_INIT	0x11
PEI_CAR_NB_INIT	0x15
PEI_CAR_SB_INIT	0x19
PEI_MEMORY_SPD_READ	0x2B
PEI_MEMORY_PRESENCE_DETECT	0x2C
PEI_MEMORY_TIMING	0x2D
PEI_MEMORY_CONFIGURING	0x2E
PEI_MEMORY_INIT	0x2F
PEI_MEMORY_INSTALLED	0x31
PEI_CPU_INIT	0x32
PEI_CPU_CACHE_INIT	0x33
PEI_CPU_AP_INIT	0x34
PEI_CPU_BSP_SELECT	0x35
PEI_CPU_SMM_INIT	0x36
PEI_MEM_NB_INIT	0x37
PEI_MEM_SB_INIT	0x3B
PEI_DXE_IPL_STARTED	0x4F
DXE_CORE_STARTED	0x60
//Recovery	
PEI_RECOVERY_AUTO	0xF0
PEI_RECOVERY_USER	0xF1
PEI_RECOVERY_STARTED	0xF2
PEI_RECOVERY_CAPSULE_FOUND	0xF3
PEI_RECOVERY_CAPSULE_LOADED	0xF4
//S3	
PEI_S3_STARTED	0xE0
PEI_S3_BOOT_SCRIPT	0xE1
PEI_S3_VIDEO_REPOST	0xE2
PEI_S3_OS_WAKE	0xE3
DXE_CORE_STARTED	0x60
DXE_NVRAM_INIT	0x61
DXE_SBRUN_INIT	0x62

5-9-2 AMI Standard - DXE

DXE_CPU_INIT	0x63
DXE_NB_HB_INIT	0x68
DXE_NB_INIT	0x69
DXE_NB_SMM_INIT	0x6A
DXE_SB_INIT	0x70
DXE_SB_SMM_INIT	0x71
DXE_SB_DEVICES_INIT	0x72

DXE_ACPI_INIT	0x78
DXE_CSM_INIT	0x79
DXE_BDS_STARTED	0x90
DXE_BDS_CONNECT_DRIVERS	0x91
DXE_PCI_BUS_BEGIN	0x92
DXE_PCI_BUS_HPC_INIT	0x93
DXE_PCI_BUS_ENUM	0x94
DXE_PCI_BUS_REQUEST_RESOURCES	0x95
DXE_PCI_BUS_ASSIGN_RESOURCES	0x96
DXE_CON_OUT_CONNECT	0x97
DXE_CON_IN_CONNECT	0x98
DXE_SIO_INIT	0x99
DXE_USB_BEGIN	0x9A
DXE_USB_RESET	0x9B
DXE_USB_DETECT	0x9C
DXE_USB_ENABLE	0x9D
DXE_IDE_BEGIN	0xA0
DXE_IDE_RESET	0xA1
DXE_IDE_DETECT	0xA2
DXE_IDE_ENABLE	0xA3
DXE_SCSI_BEGIN	0xA4
DXE_SCSI_RESET	0xA5
DXE_SCSI_DETECT	0xA6
DXE_SCSI_ENABLE	0xA7
DXE_SETUP_VERIFYING_PASSWORD	0xA8
DXE_SETUP_START	0xA9
DXE_SETUP_INPUT_WAIT	0xAB
DXE_READY_TO_BOOT	0xAD
DXE_LEGACY_BOOT	0xAE
DXE_EXIT_BOOT_SERVICES	0xAF
RT_SET_VIRTUAL_ADDRESS_MAP_BEGIN	0xB0
RT_SET_VIRTUAL_ADDRESS_MAP_END	0xB1
DXE_LEGACY_OPROM_INIT	0xB2
DXE_RESET_SYSTEM	0xB3
DXE_USB_HOTPLUG	0xB4
DXE_PCI_BUS_HOTPLUG	0xB5
DXE_NVRAM_CLEANUP	0xB6
DXE_CONFIGURATION_RESET	0xB7

5-9-3 AMI Standard - ERROR

PEI_MEMORY_INVALID_TYPE	0x50
PEI_MEMORY_INVALID_SPEED	0x50
PEI_MEMORY_SPD_FAIL	0x51
PEI_MEMORY_INVALID_SIZE	0x52
PEI_MEMORY_MISMATCH	0x52
PEI_MEMORY_NOT_DETECTED	0x53
PEI_MEMORY_NONE_USEFUL	0x53
PEI_MEMORY_ERROR	0x54
PEI_MEMORY_NOT_INSTALLED	0x55
PEI_CPU_INVALID_TYPE	0x56
PEI_CPU_INVALID_SPEED	0x56
PEI_CPU_MISMATCH	0x57
PEI_CPU_SELF_TEST_FAILED	0x58
PEI_CPU_CACHE_ERROR	0x58
PEI_CPU_MICROCODE_UPDATE_FAILED	0x59
PEI_CPU_NO_MICROCODE	0x59
PEI_CPU_INTERNAL_ERROR	0x5A
PEI_CPU_ERROR	0x5A
PEI_RESET_NOT_AVAILABLE	0x5B
//Recovery	
PEI_RECOVERY_PPI_NOT_FOUND	0xF8
PEI_RECOVERY_NO_CAPSULE	0xF9
PEI_RECOVERY_INVALID_CAPSULE	0xFA
//S3 Resume	
PEI_MEMORY_S3_RESUME_FAILED	0xE8
PEI_S3_RESUME_PPI_NOT_FOUND	0xE9
PEI_S3_BOOT_SCRIPT_ERROR	0xEA
PEI_S3_OS_WAKE_ERROR	0xEB
DXE_CPU_ERROR	0xD0
DXE_NB_ERROR	0xD1
DXE_SB_ERROR	0xD2
DXE_ARCH_PROTOCOL_NOT_AVAILABLE	0xD3
DXE_PCI_BUS_OUT_OF_RESOURCES	0xD4
DXE_LEGACY_OPROM_NO_SPACE	0xD5
DXE_NO_CON_OUT	0xD6
DXE_NO_CON_IN	0xD7
DXE_INVALID_PASSWORD	0xD8
DXE_BOOT_OPTION_LOAD_ERROR	0xD9
DXE_BOOT_OPTION_FAILED	0xDA
DXE_FLASH_UPDATE_FAILED	0xDB
DXE_RESET_NOT_AVAILABLE	0xDC

5-9-4 Intel UPI POST Codes

Initialize KTIRC ininput structure default values	0xA0
Collect info such as SBSP, Boot Mode, Reset type etc	0xA1
Setup IO SADs in SBSP to access the config space	0xA2
Setup up minimum path between SBSP & other sockets Add the node to the tree Parse the LEP of the discovered socket Check if the system has the supported topology Setup the boot path for the parent which is not directly connected to Legacy CPU Setup path from SBSP to the new found node	0xA3
Setup IO SADs in PBSP to access the config space	0xA4
System configurations that require some kind of reset	0xA5
Sync up with PBSPs	0xA6
Topology discovery and route calculation	0xA7
Program final route	0xA8
Program final IO SAD setting	0xA9
Protocol layer and other Uncore settings	0xAA
Transition links to full speed operation	0xAB
Phy layer settings	0xAC
Link layer settings	0xAD
Coherency Settings	0xAE
KTIRC is done	0xAF

5-9-5 Intel UPI Error Codes

When system BSP tries to setup path for remote sockets or sends a Boot_Go command to remote socket in SetupSbspPathToAllSockets() or SyncUpPbspForReset(). If the remote socket(s) hasn't checked-in, assert; it is a fatal condition, this error will be logged. No retry. <i>RC Behavior: System Halt</i>	0xD8
When SBSP tries to add this remote socket into system topology tree in SetupSbspPathToAllSockets(), there are some errors occur in the data structure. No retry. <i>RC Behavior: The current Socket is not added to the tree.</i> When SBSP setups the boot path for the parent which is not directly connected to Legacy CPU in SetupSbspPathToAllSockets(). The Child is not an immediate neighbor of Parent. No retry.	0xDA

SAD setup error <i>RC Behavior: System Halt</i>	0xDB
Unsupported topology <i>RC Behavior: System Halt</i>	0xDC
SBSP cannot find KPIRC TXEQ Parameters for this link in GetSocketLinkEparams(). No retry. <i>RC Behavior: System Halt</i>	0xDD

5-9-6 Intel MRC POST Codes

Detect DIMM population	0xB0
Set DDR frequency	0xB1
Gather remaining SPD data	0xB2
Program registers on the memory controller level	0xB3
Evaluate RAS modes and save rank information	0xB4
Program registers on the channel level	0xB5
DDRIO Initialization	0xB6
Train DDR	0xB7
Initialize CLTT/OLTT	0xB8
Hardware memory test and init	0xB9
Execute memory init	0xBA
Program memory map and interleaving	0xBB
Program RAS configuration	0xBC
Rank margin tool	0xBD
MRC is done	0xBF

5-9-7 Intel MRC Error Codes

No memory was detected	0xE8
Memory test failure	0xEB
Different dimm types are detected installed in the system	0xED
Number of HAs found in system greater than MAX_HA defined in MRC build	0xEE
Indicates a CLTT table structure error	0xEF
Invalid VR mode, unable to set DRAM VDD	0xF0
Failure occurred reserving memory for IOT	0xF1
Reference code assert	0xF2
Unsupported MC frequency set	0xF3
Unable to get current MC frequency	0xF4

5-9-8 Intel PM POST Codes

Start of PPM structure initialization	0xD0
PPM CSR programming	0xD1
PPM MSR programming	0xD2
Start of PState transition init	0xD3
PPM exit	0xD4
PPM On ready to boot event	0xD5

5-9-9 Intel PM POST Codes

Start of IIO early Initialization	0xE0
Pre Link training	0xE1
Start of Gen3 EQ training	0xE2
Start of PState transition init	0xE3
Gen3 parameters override	0xE4
End of IIO Early Initialization	0xE5
Start of IIO Late initialization	0xE6
PCIE port initialization	0xE7
IOAPIC initialization	0xE8
VTD initialization	0xE9
IOAT initialization	0xEA
DFX initialization	0xEB
NTB initialization	0xEC
Security Initialization	0xED
IIO late initialization	0xEE
IIO On ready to boot event	0xEF

5-10 BIOS POST Beep code (AMI standard)

5-10-1 PEI Beep Codes

# of Beeps	Description
1	Memory not Installed.
1	Memory was installed twice (InstallPeiMemory routine in PEI Core called twice)
2	Recovery started
3	DXE IPL was not found
3	DXE Core Firmware Volume was not found
4	Recovery failed
4	S3 Resume failed
7	Reset PPI is not available

5-10-2 DXE Beep Codes

# of Beeps	Description
1	Invalid password
4	Some of the Architectural Protocols are not available
5	No Console Output Devices are found
5	No Console Input Devices are found
6	Flash update is failed
7	Reset protocol is not available
8	Platform PCI resource requirements cannot be met