

## **INSTALLATION INSTRUCTIONS:**

Note the cable routing detailed in Image 1, Detail A.

D

С

Insert the connector from the Protective Case into the Apple iPad (7th Gen).

Place the iPad into the Rear Protective Case and ensure that the cable routing matches that shown in Detail A. Be careful not to pinch the cable.

Place Front Protective Case onto the rear, noting that the Havis logo should be positioned on the bottom side (connector side) of the iPad. Ensure that the cable is not pinched when placing the two halves together.

Your Protective Case includes four (4) snapfits near the center of the case. Apply light pressure until all the snaps are interlocked.

Holding the two halves of the Protective Case together carefully turn the Protective Case over.

Fasten all eight (8) of the M2.5 x 6mm screws (Item #1) with the supplied T8 torx bit (Item #2) into locations shown in Image 3. Torque to 4 in-lbs +/- 10%. Do not overtighten screws.

NOTE: Hardware kit includes extra screws in the event of loss or damage.

 

 PRODUCT I.D.
 DATE

 TC-107
 01-17-20

 PRODUCT NAME
 INSTALLATION INSTRUCTIONS FOR TC-107

 MEIGHT: (LBS)
 1.573

 1-800-524-9900 WWW.HAVIS.COM
 REV. DATE 01-20

2

