

Intermec's FlexDock System

A uniquely scalable and modular docking system giving users the flexibility to design the docking system that best suites their needs today, as well as in the future.

Accessories Guide

CONTENTS

Design Your Own:

- Bases 1
- Desktop Modules 2
- Power Supplies 2
- AC Line Cords 2
- Mobile Computer Cups 3
- Mobile Printer Cups 3
- Mobile Scanner Cups 3
- Mobile Computers and Printers Battery Cups 4
- Covers 4
- Mounting Kits 4

Common Mixed Configurations.....

5







Pre-Configured:

- CN70 & CN70e FlexDocks 6
- CN3, CN3e, CN4 & CN4e FlexDocks 7
- CN50 FlexDocks 7
- CS40 FlexDocks 8
- CK70 & CK71 FlexDocks 9
- CK3 FlexDocks 10
- Mobile Receipt Printers 11
- Mobile Scanner FlexDocks 11



*Design Your Own:
Choose your Base and add the appropriate Cups, Power Supply and Line Cord.*

Bases

Accessory Name	Part Number	Description
 Quad Charge Only	852-916-002	Provides 4 bays for charging individual devices and/or battery packs. Power supplies and country specific line cords must be ordered separately.
 Quad Ethernet	852-917-002	Provides 4 bays for Ethernet communications and charging individual devices and/or battery packs. Power supplies and country specific line cords must be ordered separately.
 Dual Charge Only	852-918-002	Provides 2 bays for charging individual devices and/or battery packs. Power supplies and country specific line cords must be ordered separately.
 Dual Ethernet	852-919-002	Provides 2 bays for Ethernet communications and charging individual devices and/or battery packs. Power supplies and country specific line cords must be ordered separately.
 Desktop	852-920-002	Provides (2) bays with dedicated functionality. Bay 1: Accommodates mobile device for charging and Ethernet or modem or USB host communications, as well as USB client connectivity. Ethernet and modem communications require add-on modules listed below. Bay 2: Used for charging up to (2) batteries. Power supplies and country specific line cords must be ordered separately.
 Assembled Desktop Dock		Bay 1: Computer Cup Bay 2: Dedicated Battery Cup

Intermec's FlexDock System

Accessory Guide

Desktop Modules

Accessory Name	Part Number	Description
Desktop Dock Ethernet Module	871-238-011	Module plugs into USB port of Desktop base to provide Ethernet communications.



Desktop Dock
w/ Ethernet
Module



Ethernet Module

Desktop Dock Modem Module	871-238-002	Module plugs into USB port of Desktop base to provide modem communications.
---------------------------	-------------	---

Power Supplies

Accessory Name	Part Number	Description
Quad Base Power Supplies	851-064-327	A 100W power supply for use with Quad Charge Only and Quad Ethernet Bases. Requires country specific line cord to be ordered separately.



Dual or Desktop Base Power Supply	851-095-131	A 48W power supply for use with Dual Charge Only, Dual Ethernet, and Desktop Bases. Requires country specific line cord to be ordered separately.
-----------------------------------	-------------	---









AC Line Cords

Power Cord - China	071918
Power Cord - Europe	1-974027-025
Power Cord - UK	1-974029-020
Power Cord - Australia	1-974030-025
Power Cord - Italy	321-471-002
Power Cord - Japan	321-500-002
Power Cord - Denmark	321-501-002
Power Cord - India/S Africa	321-502-002
Power Cord - US	1-074028-025
Power Cord - Switzerland	321-470-001


Intermec's FlexDock System

Accessory Guide


Mobile Computer Cups

Accessory Name	Part Number	Description
 CK3 Mobile Computer Cup	203-916-001	Supports (1) mobile computer when snapped into a bay of base unit.
 CK70/71 Mobile Computer Cup	203-921-001	Supports (1) mobile computer when snapped into a bay of base unit.
 CN3(e)/CN4(e) Mobile Computer Cup	203-914-001	Supports (1) mobile computer when snapped into a bay of base unit.
 CN50 Mobile Computer Cup	203-918-002	Supports (1) mobile computer when snapped into a bay of base unit.
 CN70/70e Mobile Computer Cup	203-920-001	Supports (1) mobile computer when snapped into a bay of base unit.
 CS40 Mobile Computer Cup	203-923-001	Supports (1) mobile computer when snapped into a bay of base unit.

Mobile Printer Cups

Accessory Name	Part Number	Description
 PR2/PR3 Mobile Receipt Printer Cup	203-964-001	Supports (1) mobile printer when snapped into a bay of base unit.





Mobile Scanner Cups

Accessory Name	Part Number	Description
 SF61B Scanner Cup	213-007-001	Supports (2) scanners when snapped into a bay of base unit.

Intermec's FlexDock System

Accessory Guide


Mobile Computers and Printers Battery Cups

Accessory Name	Part Number	Description
CK70/71 & CK3 Battery Cup	203-917-001	Supports charging of (2) batteries when snapped into a bay of base unit.
		
CN70/70e Battery Cup	203-922-002	Supports charging of (2) batteries when snapped into a bay of base unit.
		
CS40 Battery Cup	203-924-001	Supports charging of (2) standard batteries when snapped into a bay of base unit.
		
PR2/PR3 Mobile Receipt Printer Battery Cup	203-965-001	Supports charging of (2) batteries when snapped into a bay of base unit.
		

Covers

Accessory Name	Part Number	Description
Blank Cover	203-926-001	Optional cover for base bays currently not in use. Intended to prevent debris from accumulating on exposed bay contacts.




Mounting Kits

Accessory Name	Part Number	Description
Wall Mounting Kit	203-641-002	Consists of (1) metal rack with pre-drilled holes for securing FlexDock bases and mounting to wall surface. Also used with 700 Series, CK61, and CN3 / CN4 Series.
Rack Mounting Kit	203-945-001	Consists of (1) metal rack with pre-drilled holes for securing FlexDock bases and for mounting vertically to uprights of standard 19" (48 cm) IT equipment rack. Includes thumbscrews and two adapters for mounting racks upto 15 degree angle for better viewability. (Standard IT rack must be ordered separately.)
		

Intermec's FlexDock System

Accessory Guide

Common Mixed Configurations:

Accessory Name	Part Numbers	Description
 <p>CN50/PR2 Dual Charge</p>	<p>852-918-001 203-918-001 203-964-002 851-095-131</p>	<p>Supports charging (1) CN50 computer and (1) PR2 or PR3 receipt printer. Country specific line cords must be ordered separately.</p>
 <p>CN70/PR2 Dual Charge</p>	<p>852-918-001 203-920-001 203-964-002 851-095-131</p>	<p>Supports charging (1) CN70 or CN70e computer and (1) PR2 or PR3 receipt printer. Country specific line cords must be ordered separately.</p>
 <p>PR2/3 Battery and Printer Quad Charge</p>	<p>852-916-001 203-964-001 x 2 203-965-001 x 2 851-064-327</p>	<p>Support charging (4) PR2/3 battery packs and (2) PR2 or PR3 printers. Country specific line cords must be ordered separately.</p>










For additional options, see the "Design Your Own" Section.

Intermec's FlexDock System

Accessory Guide

*Pre-Configured:
Ready to Go out of the box.*

CN70 & CN70e FlexDocks

Accessory Name	Part Number	Description
CN70/70e Quad Charge Only 	DX4A2111100 DX4A2111110 (incls NA cord)	Supports charging for up to (4) CN70 and/or CN70e computers. Includes power supply. Country specific line cords must be ordered separately.
CN70/70e Quad Ethernet  	DX4A1111100 DX4A1111110 (incls NA cord)	Supports Ethernet communications and charging for up to (4) CN70 and/or CN70e computers. Includes power supply. Country specific line cords must be ordered separately.
CN70/70e Dual Charge Only 	DX2A21120 DX2A21110 (incls NA cord)	Supports charging for up to (2) CN70 and/or CN70e computers. Includes power supply. Country specific line cords must be ordered separately.
CN70/70e Dual Ethernet  	DX2A11120 DX2A11110 (incls NA cord)	Supports Ethernet communications and charging for up to (2) CN70 and/or CN70e computers. Includes power supply. Country specific line cords must be ordered separately.
CN70/70e Desktop 	DX1A01A20 DX1A01A10 (incls NA cord)	Supports (1) CN70 or CN70e computer for charging and Ethernet or modem or USB host communications, as well as USB client connectivity; and battery charging for up to (2) CN70/e batteries. Ethernet and modem communications require add-on modules listed under "Design Your Own" section. Includes power supply. Country specific line cords must be ordered separately.
CN70/70e 4-Position Battery Charger 	DX2A2AA20 DX2A2AA10 (incls NA cord)	Supports charging for up to (4) CN70 or CN70e batteries. Includes power supply. Country specific line cords must be ordered separately.
CN70/70e 8-Position Battery Charger 	DX4A2AAAA00 DX4A2AAAA10 (incls NA cord)	Supports charging for up to (8) CN70 or CN70e batteries. Includes power supply. Country specific line cords must be ordered separately.

Intermec's FlexDock System

Accessory Guide

CN3, CN3e, CN4 & CN4e FlexDocks

Accessory Name	Part Number	Description
CN3/CN4 Quad Charge Only	DX4A2333300 DX4A2333310 (incls NA cord)	Supports charging for up to (4) CN3/e and/or CN4/e computers. Includes power supply. Country specific line cords must be ordered separately.



CN3/CN4 Quad Ethernet	DX4A1333300 DX4A1333310 (incls NA cord)	Supports Ethernet communications and charging for up to (4) CN3/e and/or CN4/e computers. Includes power supply. Country specific line cords must be ordered separately.
-----------------------	--	--



Back View

CN50 FlexDocks

Accessory Name	Part Number	Description
CN50 Quad Charge Only	DX4A2555500 DX4A2555510 (incls NA cord)	Supports charging for up to (4) CN50 computers. Includes power supply. Country specific line cords must be ordered separately.



CN50 Quad Ethernet	DX4A1555500 DX4A1555510 (incls NA cord)	Supports Ethernet communications and charging for up to (4) CN50 computers. Includes power supply. Country specific line cords must be ordered separately.
--------------------	--	--












Back View

Intermec's FlexDock System

Accessory Guide










CS40 FlexDocks

Accessory Name	Part Number	Description
 <p>CS40 Quad Charge Only</p>	<p>DX4A2666600 DX4A2666610 (incls NA cord)</p>	<p>Supports charging for up to (4) CS40 computers. Includes power supply. Country specific line cords must be ordered separately.</p>
  <p>CS40 Quad Ethernet</p>	<p>DX4A1666600 DX4A1666610 (incls NA cord)</p>	<p>Supports Ethernet communications and charging for up to (4) CS40 computers. Includes power supply. Country specific line cords must be ordered separately.</p>
 <p>CS40 Dual Charge Only</p>	<p>DX2A26620 DX2A26610 (incls NA cord)</p>	<p>Supports charging for up to (2) CS40 computers. Includes power supply. Country specific line cords must be ordered separately.</p>
  <p>CS40 Dual Ethernet</p>	<p>DX2A16620 DX2A16610 (incls NA cord)</p>	<p>Supports Ethernet communications and charging for up to (2) CS40 computers. Includes power supply. Country specific line cords must be ordered separately.</p>
 <p>CS40 Desktop</p>	<p>DX1A06E20 DX1A06E10 (incls NA cord)</p>	<p>Supports (1) CS40 computer for charging and Ethernet or modem or USB host communications, as well as USB client connectivity; and battery charging for up to (2) standard CS40 batteries. Ethernet and modem communications require add-on modules listed under "Design Your Own" section. Includes power supply. Country specific line cords must be ordered separately.</p>
 <p>CS40 4-Position Battery Charger</p>	<p>DX2A2EE20 DX2A2EE10 (incls NA cord)</p>	<p>Supports charging for up to (4) standard CS40 batteries. Includes power supply. Country specific line cords must be ordered separately.</p>
 <p>CS40 8-Position Battery Charger</p>	<p>DX4A2EEEE00 DX4A2EEEE10 (incls NA cord)</p>	<p>Supports charging for up to (8) standard CS40 batteries. Includes power supply. Country specific line cords must be ordered separately.</p>

Intermec's FlexDock System

Accessory Guide






CK70 & CK71 FlexDocks

Accessory Name	Part Number	Description
 <p>CK70/71 Quad Charge Only</p>	<p>DX4A2222200 DX4A2222210 (incls NA cord)</p>	<p>Supports charging for up to (4) CK70 and/or CK71 computers. Includes power supply. Country specific line cords must be ordered separately.</p>
  <p>CK70/71 Quad Ethernet</p>	<p>DX4A1222200 DX4A1222210 (incls NA cord)</p>	<p>Supports Ethernet communications and charging for up to (4) CK70 and/or CK71 computers. Includes power supply. Country specific line cords must be ordered separately.</p>
 <p>CK70/71 Dual Charge Only</p>	<p>DX2A22220 DX2A22210 (incls NA cord)</p>	<p>Supports charging for up to (2) CK70 and/or CK71 computers. Includes power supply. Country specific line cords must be ordered separately.</p>
  <p>CK70/71 Dual Ethernet</p>	<p>DX2A12220 DX2A12210 (incls NA cord)</p>	<p>Supports Ethernet communications and charging for up to (2) CK70 and/or CK71 computers. Includes power supply. Country specific line cords must be ordered separately.</p>
 <p>CK70/71 Desktop</p>	<p>DX1A02B20 DX1A02B10 (incls NA cord)</p>	<p>Supports (1) CK70 or CK71 computer for charging and Ethernet or modem or USB host communications, as well as USB client connectivity; and battery charging for up to (2) CK70, CK71 or CK3 batteries. Ethernet and modem communications require add-on modules listed under "Design Your Own" section. Includes power supply. Country specific line cords must be ordered separately.</p>
 <p>CK70/71 4-Position Battery Charger</p>	<p>DX2A2BB20 DX2A2BB10 (incls NA cord)</p>	<p>Supports charging for up to (4) CK7x or CK3 batteries. Includes power supply. Country specific line cords must be ordered separately.</p>
 <p>CK70/71 8-Position Battery Charger</p>	<p>DX4A2BBBB00 DX4A2BBBB10 (incls NA cord)</p>	<p>Supports charging for up to (8) CK7x or CK3 batteries. Includes power supply. Country specific line cords must be ordered separately.</p>

Intermec's FlexDock System

Accessory Guide

CK3 FlexDocks

Accessory Name	Part Number	Description
CK3 Quad Charge Only 	DX4A2444400 DX4A2444410 (incls NA cord)	Supports charging for up to (4) CK3 computers. Includes power supply. Country specific line cords must be ordered separately.
CK3 Quad Ethernet   <p style="text-align: center;">Back View</p>	DX4A1444400 DX4A1444410 (incls NA cord)	Supports Ethernet communications and charging for up to (4) CK3 computers. Includes power supply. Country specific line cords must be ordered separately.
CK3 4-Position Battery Charger 	DX2A2BB20 DX2A2BB10 (incls NA cord)	Supports charging for up to (4) CK3 and/or CK7x batteries. Includes power supply. Country specific line cords must be ordered separately.
CK3 8-Position Battery Charger 	DX4A2BBBB00 DX4A2BBBB10 (incls NA cord)	Supports charging for up to (8) CK3 and/or CK7x batteries. Includes power supply. Country specific line cords must be ordered separately.

Intermec's FlexDock System

Accessory Guide

Mobile Receipt Printers FlexDocks

Accessory Name	Part Number	Description
PR2/3 Quad Charge Only	DX4A277700 DX4A277710 (incls NA cord)	Supports charging for up to (4) PR2 or PR3 receipt printers. Includes power supply. Country specific line cords must be ordered separately.
PR2/3 Dual Charge Only	DX2A27710 (incls NA cord) DX2A27720	Supports charging for up to (2) PR2 or PR3 receipt printers. Includes power supply. Country specific line cords must be ordered separately.
PR2/3 4-Position Battery Charger	DX2A2FF10 (incls NA cord) DX2A2FF20	Supports charging for up to (4) PR2 or PR3 batteries. Includes power supply. Country specific line cords must be ordered separately.
PR2/3 8-Position Battery Charger	DX4A2FFF00 DX4A2FFF10 (incls NA cord)	Supports charging for up to (8) PR2 or PR3 batteries. Includes power supply. Country specific line cords must be ordered separately.



Mobile Scanner FlexDocks

Accessory Name	Part Number	Description
SF61B 4-Position Charger	DX2A28810 DX2A28820	Supports charging for up to (4) SF61B scanners. Includes power supply. Country specific line cords must be ordered separately.

