



The perfect combination.

Balance is a wireless keyboard designed as the perfect match for the RollerMouse Red or Free. We are particularly pleased to be able to provide the option to incline the keyboard, angling it conveniently away from you. Strategically positioned, more touch-sensitive keys reduce strain on the hands, arms and shoulders. Briefly put, the combination of a Balance keyboard and RollerMouse puts everything within easy reach.



Emphasis on comfort

Make the very most of your working position, keyboard and mouse. The Balance Keyboard/ RollerMouse combination puts you in control. You can adjust the angle and height of the keyboard, the mouse speed and many other properties to match your own preferences. The keyboard is ideal for use with the latest models in the RollerMouse range.

More functions close at hand

The media keys provide direct access to smart functions, and it is simple to reprogram them if you wish. Naturally, the keyboard also features the standard function keys (F1–F12), which are ready for use as soon as you press the key that locks the Fn function.

Wireless and free

It's time to cut the cord! The Balance keyboard is wireless and powered by two AAA-batteries. You connect it to your computer or Mac using the USB receiver supplied, which is fixed magnetically in place in the battery compartment when not in use.

Keyboard overview

- A. Media control
- B. Software functions
- C. Interface functions
- D. Volume setting
- E. Fn key
- F. Indicator light for:
 - Low battery power
 - Caps lock
 - FN lock



Get started



Step 1:

Open the compartment on the rear side and insert the AAA-batteries. Remove the wireless receiver from the compartment.



Step 2:

Insert the wireless receiver in a vacant USB port.



Step 3:

Start using your Balance keyboard.

| Technical specifications | |
|--------------------------|-------------------------------|
| Width | 39,2 cm |
| Depth | 11,9 cm |
| Height | 2,05 cm |
| Buttons | 12 programmable buttons |
| Connection | Wireless USB receiver |
| Battery | AAA type |
| Battery lifetime | Up to 12 months |
| Installation | Plug-and-play |
| Driver needed | No |
| Warranty | 2 years from date of purchase |
| Compatibility | PC and Mac |